



SYSTEM OF NARCOTICS IDENTIFICATION

INSTRUCTIONS FOR USE

TEST S - KN REAGENT

FOR: Marijuana (dried and green leaf), Seeds,
Hashish, "Hash Oil" and THC

Test Function

1. This reagent system presumptively identifies Marijuana, Hashish, "Hash Oil" and THC.

How to Use Test E

1. Amount of material required for testing:
 - A) Marijuana, use 3-7 particles of plant material. Too much material will cause a radical color change, making identification difficult.
 - B) Hashish, use a small fragment
 - C) "Hashish Oil," use a small drop on a tip of Loading Device or a 6mm x 6mm (1/4" x 1/4") piece of filter paper or tissue paper.
 - D) THC, use only a very small amount of product material that would approximate the size of a period (.).
2. Remove clip, insert material into test pack, reseal with clip and tap gently to assure material falls to bottom of pack.
3. With printed side of test pack facing you, break ampoules from left to right by squeezing the center of the ampoule with tips of thumb and forefinger. Agitate gently and observe color or color changes.
4. Break the left ampoule, agitate vigorously for about 30 seconds. (No color, other than a field or dust color, will form at this point).
5. Break the right ampoule and agitate gently. An orange or reddish brown color will develop within a few seconds to a minute if Marijuana, Hashish, "Hash Oil" or THC is present. Following the development of the color change, a layering of clear over reddish brown will develop indicating a positive test.

CAUTION

No attempt should be made to crush the glass particles after the ampoules are broken.

Since these tests contain strong acids, it is suggested that Test F (Acid Neutralizer) be used after testing and before disposal. Before discarding used test packs, remove clip and add one measure of acid neutralizer from Test F. Add slowly to prevent bubbling over. DO NOT reseal the test pouch until effervescence has completely stopped. Reseal pouch with clip and discard in a tamper-free disposal unit.

Antidote: In case of contact, immediately flush eyes or skin with water for at least 15 minutes while removing contaminated clothing and shoes. If swallowed, do not give emetics. Contact a physician.

WARNING

These tests are NOT designed for use with liquid samples.



13386 International Parkway
Jacksonville, Florida 32218
904.347.1200 FAX: 904.741.5407
© 2019 Safariland, LLC

A Brand of the Safariland Group