

POWERZONE SERIES

POWERZONE 100

OPERATING INSTRUCTIONS

Based on the size of the room being sterilized, set the timer to according amount.

- Plug unit into standard 110v outlet.
- For In-room sterilization: place the system in room and set timer using (+/-) according to chart below.
- Clear room of all people and pets and close the door
- Re-enter the room 10-15 minutes after cycle has completed. Unit will automatically turn off once timer runs out.
- Optional remote room sterilization: connect tube and place end of tube in empty room (e.g. under door). Turn on system.
- Optional produce sterilization: Submerge produce in a bowl of water. Please tube end (with soapstone) in water. Run for 10 minutes.
- Optional clothes/loose item sterilization: place clothes/other articles in a plastic bag or plastic bin. Place tube end into bag or cut a small hole in plastic bin to insert tube. Run system for 10 minutes.



Tube Connection Point

60-minute Timer
Set timer according to the chart below

| Room Size | Run Time | O3 Dissipation Time |
|------------------|----------|---------------------|
| 500 - 1000 cu ft | 60 min | 15 min |
| 400 - 500 cu ft | 45 min | 15 min |
| 200 - 400 cu ft | 30 min | 10 min |
| 100 - 200 cu ft | 20 min | 10 min |
| Up to 100 cu ft | 10 min | 10 min |

IMPORTANT PRECAUTION

While Ozone is a highly effective sterilizer it is known to cause respiratory agitation. People and pets should not enter a room until 10 to 15 minutes after the Powerzone cycle has finished.