



Re-Useable Cold Packs

Great for use with non-refrigerated carts or extra protection in extreme conditions

Eliminate Wet & Dry Ice Hassles Forever

Before each use, freeze the eutectic liquid contained in the plate. To do this, place the plate in a freezer at a temperature at least 10 degrees below the set point of the plate for 24-48 hours until it is completely solid. Freeze the plate in a flat position. Handle with care when frozen as it is sensitive to shock. Do not expose to high heat (120 deg F.) .



GN1/1

COOL™ Eutectic Plates are available in the following temperatures:

+26 Deg F. -requires +10 to freeze

+3 Deg F. -requires -10 to -15 to freeze

-6 Deg F. -requires -15 to freeze

Choose plate temperature closest to the temperature of your product

Plates GN1/1

Size : 20.75" x 12.75" x 1"

Weight 7 lbs

Plates GN1/2

12.75" X 10.5" x 1"

Weight 5 lbs