

NEXVOO FOCUS


UH15 UC Headset



User Guide



1. Outer Configuration



- 1. 3.5mm Stereo Plug
- 2. Microphone
- 3. Gooseneck Mic Boom
- 4 Far cover
- 5 Headband
- 6. Speaker
- 7. Swing Boom
- 8. Clip
- 9. Adjustable Headband
- 10. T-Pad


2. Headband



Headband can be adjusted max. at 40mm(monaural) or 80mm(binaural) to meet different people's requirements for comfort wearing.



3




Swing boom is 330°rotatable.

Position the microphone boom to leave
a width of 30-50mm between the lower
lip and microphone for best communicating
position.

Notes:Don't rotate the boom over 330°!






Speaker assembly jointed max. at 180° to adjust the ear cushion for comfort wearing.



Do not use headset with high volume for extra long time, which may cause hearing loss. Always listen at a moderate level.





FUNCTION

- In-line microphone mute: press the mute button to activate mute, perss again to de-activate mute
- 2. Microphone mute LED indicator(red)
- In-line speaker volume controller: press "+" to increase speaker volume, press "-" to decrease speaker volume
- In-line hook to answer/end call: press the button to answer the call. press again to end the call
- 5. Hook LED indicator(blue)

SETUP

Connect the USB adaptor into any USB port on the computer. Plug and play, not require software installation.

NOTE

- The in-line hook is specially designed for Microsoft Teams&Skype for Business, it may not be available for other systems.
- You are required to install "Skypeheadset" on your PC if you want to use HOOK function on Skype.
- Please contact with your supplier to get the "Skypeheadset" installation file



| | Tox | Toxic and Hazardous Substances Composition | | | | | | | |
|---|------------|--|---------|-------|---------------|------|--|--|--|
| Element | Pb | Hg | Cd | Cr-VI | PBB | PBDE | | | |
| Mounted Electronic componer on Surface | c its O | 0 | 0 | 0 | 0 | 0 | | | |
| Microphor | ne O | 0 | 0 | 0 | 0 | 0 | | | |
| X: it represents at least one toxic and hazardous substance content higher than the requirement of SJ/T11364-2006 | | | | | | | | | |
| O: it represents all the toxic and hazardous substance content lower than the requirement of SJ/T11364-2006 | | | | | | | | | |
| Product Warranty Card | | | | | | | | | |
| Customer Name | | Tel. No. | | | CHECKING CARD | | | | |
| Model No. | | Date of Purchase | | | | | | | |
| Customer A | ddress: | | | | | | | | |
| Problem De | scription: | | OQC: | | | | | | |
| Microphone | Speaker | Bottom Co | ord Oth | iers | | | | | |
| | | | | | | | | | |
| Repaired Da | ate: | | | | | | | | |





LIMITED WARRANTY.

- This warranty covers defects in materials and workmanship of Commercial Products manufactured, sold or certified by Nexvoo.
- This warranty lasts for one years from the date of purchase of the Products.
- This warranty extends to you only if you are the end user with the original purchase receipt.
- We will, at our option, repair or replace the Products that do not conform to the warranty. We may use functionally equivalent reconditioned/refurbished/ remanufactured/pre-owned or new Products or parts.
- THIS IS NEXVOO'S COMPLETE WARRANTY FOR THE PRODUCTS.
- This warranty gives you specific legal rights, and you may also have other rights. Please contact your dealer or our service center for the full details of our limited warranty, including items not covered by this limited warranty.

Nexvoo Inc.

NEXVOO® US

103*126mm

| 名 称: | CD 4000 nove to 111145 | 制定 | | | 日期 | 2020/0907 | |
|--------|-------------------------------|----|-----|---|----|-----------|-----|
| 4D 4M. | SP-1233nexvoo UH15 UC耳机说明书 | 审核 | | | 日期 | | |
| 材 彩 | : | | 批准 | | | 日期 | |
| | | | 投 影 | 法 | 单位 | 比 例 | 版本 |
| 机种 | 1: | | 第 1 | 角 | mm | | A/3 |

图 号: SP-1233 Nexvoo Inc.