

## Verratek Nimble 2 Smartwatch

### Troubleshooting:

**NOTE:** This is not a medical device, and data is not 100% accurate.

**Bluetooth Connectivity:** To connect to Device to Bluetooth, ensure BT Power is ON and Visibility is ON. Found under Settings -> BT Settings. Still not connecting? Restart devices and try again.

**Music Companion:** Must be connected to device. Smartwatch only controls the music on your phone and does not act as a bluetooth speaker.

**Heart Rate:** Data only monitored during "Sports Modes and Heart Rate Test" and stops when finished. Turn on "Heart Rate", you'll notice the green sensor activate on the back of the smartwatch, allowing up to 1 minute to gather data.

**Blood Pressure:** Data only active during "Blood Pressure" Test and stops when finished. Turn on "Blood Pressure", you'll notice the green sensor activate on the back of the smartwatch, allowing up to 1 minute to gather data.

**Blood Oxygen:** Data only active during "Blood Oxygen" Test and stops when finished. Turn on "Blood Oxygen", you'll notice the green sensor activate on the back of the smartwatch, allowing up to 1 minute to gather data.

**Sleep Monitoring:** Data only monitored from 9PM to 9AM