
How to Use

- Plug the Type-C connector into the corresponding slot on your mains plug or computer.
- Position your MagTec wireless charger in the central area on the back of your phone and allow the magnets to lock on (iPhone 12 Mini, 12, 12 Pro & newer models).
- 3 Your phone will begin charging.

Notes:

iPhone 12 & newer models can be charged wirelessly by direct magnetic attraction; other mobile phones that support wireless charging can be charged by placing the MagTec Wireless charger flat on the table/desk and positioning the central area of the back of the phone onto the MagTec Wireless charger



Notes:

The effectiveness of the magnetic connection is weakened when using with a protective phone case. Only original iPhone MagSafe® cases guarantee compatibility with the magnets in the MagTec Wireless Charger. Third-party magnetic cases can't guarantee full compatibility.





8

FOR 1-YEAR WARRANTY

Caution: If the batch code is removed from the product, the warranty will be void.

Let's get techy



Made from 90% recycled plastics 18% of the material on this product is made from recycled post consumer waste plastic.

Input Power	DC5V/3A, 9V/2.22A, 12V/1.67A
Output Power	15W/10W/7.5W/5W/2.5W
Adapter	QC 2.0, QC 3.0, PD20W (recommended)
Dimensions	H56mm x W56mm x D5mm
Cable length	2m
Compatibility	7.5W Max for Apple devices, 10W Max for Samsung devices, 2.5W Max for TWS



MIRELESS CHARGER

Precautions

- Please confirm whether your mobile phone supports wireless charging.
 Otherwise it will not be able to charge your mobile phone.
- Avoid putting any metal materials, magnets or credit cards on your phone or protective case, as this may affect the wireless charge.
- Use a protective case no larger than 2mm thickness to ensure both the magnetic connection and wireless charging functions properly.
- 4. Do not attempt to disassemble this product yourself due to risk of electric shock.
- Do not use this product in severe high temperatures, humidity or corrosive conditions to avoid electrical leakage & circuit damage.
- Do not splash water or liquids on the wireless charger. If you need to clean up, please make sure the power is disconnected first.
- When charging, please keep the distance between implanted medical equipment (pacemaker, implantable cochlea, etc.) and wireless charger at 20cm to avoid potential interference to medical equipment.
- 8. Keep out of reach of children.

Email: customerservices@juice.co.uk @Juice. Juice®. 10 Hastemere Way. OX16 5RW. UK. Box 133, 3 Lombard Street East, Dublin 2, D02 HC78, Ireland. Helpline no.: +35315256712



The Juice® MagTec Wireless Charger can only be used with compatible products. Please read your equipments compatibility instructions to determine whether this Juice® MagTec Wireless Charger matches your equipment instructions to determine whether this Juice® MagTec Wireless Charger matches your equipment requirements. The manufacturer will not be held responsible for any equipment or accessories not suitable for use with the Juice® MagTec Wireless Charger. The manufacturer will not be held liable for damage acused by misuse or damage incurred by the buyer or the third party rising from any intentional or unintentional use of the Juice® MagTec Wireless Charger. Juice declares that this product complies with the essential requirements and relevant provisions of Directive 2014/53/EU.