



MokiTag Card

Quick Start Guide

View complete MokiTag digital user guide here



MokiTag Card

Quick Start Guide

1. Unlock your iDevice and place it near your MokiTag Card.
2. Open the Find My app.
2. Click the "+" icon to add a new device.
3. Click on "Add Other Item".
4. Press the button on the front of your MokiTag Card to activate pairing.
5. When detected, product ID **ACC-MTAGC** appears. Click "**Connect**".
6. Name your MokiTag Card and click "**Continue**".
7. Select an Emoji to represent your MokiTag Card.
8. Read terms and click "**Agree**".

Your MokiTag Card is now paired and ready for use.