



As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

| | | | | |
|------------------|----------|---|--|--------|
| Test Preparation | 1 | Remove the Smart-Tip [™] probe from test unit. | 2 Sample suspected substance. | |
| | | | Substance | Tablet |
| | | <p>Touch the Smart-Tip[™] probe to the sample.</p> | <p>Firmly press Smart-Tip[™] probe on the tablet while scrubbing in a circular motion until the tip is completely covered with substance.</p> | |

| | | | | | | | |
|------------------|----------|---|---|----------------|--|----------|--|
| Test Preparation | 3 | Lock Smart-Tip [™] probe into test unit. Press firmly. | STOP Do not continue unless probe is locked below the Flex Pins and cannot be removed from the test unit. | 4 | With thumb and forefinger , squeeze chamber 1 until capsule breaks. | 5 | Gently shake test unit for 10 seconds. |
| | | | | Identification | | | |

| | | | | |
|----------------|----------|--|----------|--|
| Identification | 6 | With thumb and forefinger , squeeze chamber 2 until capsule breaks. | 7 | Gently shake test unit for 10 seconds. |
| | | | | |

| | |
|---------|--|
| Results | <p>The appearance of blue color particles adhering to the sampler tip or in the solution within one minute indicates the presence of PCP (Phencyclidine). * Note: The liquid will remain dark pink.</p> |
| | <p>If no blue color develops within one minute, PCP is not present.</p> |

| | |
|----------|--|
| Disposal | The test kit is safe to dispose of in the trash. |
|----------|--|

IMPORTANT INFORMATION

- IDenta Touch&Know[™] Discreet Drug Test Kits** are used to determine the presence of certain drugs in substances such as powders, crystals, granules, flakes, pills, tablets, or liquids.
- All results are presumptive.** If necessary, further testing by a competent drug testing lab can provide additional verification.
- A color change indicates a positive result for the listed drugs only if it occurs within the first minute.**

If there is **NO** color change within the time indicated, the listed drugs are **NOT** present in the tested sample. After a minute, the sampler and the liquid may begin changing color as a normal part of the testing process and this color change does **NOT** indicate a positive result.

| | |
|--|---|
| <p>IDenta World Leader in Forensic Products</p> | <p>Manufactured by IDenta Ltd</p> <p>www.touch-know.com</p> <p>info@touch-know.com</p> |
|--|---|