

## Sanitize all the surfaces in your life.




Testing was conducted in a laboratory setting. Direct exposure to UV-C light is required to kill bacteria and viruses. Surface areas not directly exposed may not eliminate pathogens to the above levels. Real world results may vary depending on size, shape, and material of surface. Additional testing is currently being performed. Please check our website for the latest testing data. For more information, please contact your **VitaLight**<sup>™</sup> representative.

Device	Micro-organism	Time	Distance	Sterilization Rate	Log Reduction	Lab
	Staphylococcus aureus (Staph)	15s	2cm (0.78")	»99.99%	4-Log	SGS
	Escherichia coli (E. Coli)	15s	2cm (0.78")	>99.9%	3-Log	SGS
GoWand for Android Devices	Staphylococcus aureus (Staph)	15s	3cm (1.18")	>99.9%	3-Log	SGS
	Escherichia coli (E. Coli)	15s	3cm (1.18")	>99.9%	3-Log	SGS
	SARS-CoV-2 (COVID-19 Virus)	10s	2/3"	>99.9%	3-Log	CUBRC
	SARS-CoV-2 (COVID-19 Virus)	15s	1"	>99%	2-Log	CUBRC
	Staphylococcus aureus (Staph)	15s	2cm (0.78")	>99.9%	3-Log	SGS
	Escherichia coli (E. Coli)	15s	2cm (0.78")	>99.9%	3-Log	SGS
GoWand for Apple Devices	Staphylococcus aureus (Staph)	15s	3cm (1.18")	>99%	2-Log	SGS
	Escherichia coli (E. Coli)	15s	3cm (1.18")	>99%	2-Log	SGS
	SARS-CoV-2 (COVID-19 Virus)	15s	1"	>99%	2-Log	CUBRC
	Staphylococcus aureus (Staph)	10m	N/A	>99.99%	4-Log	SGS
Gen 1 UVC Sanitizer Box	Escherichia coli (E. Coli)	10m	N/A	>99.99%	4-Log	SGS
	SARS-CoV-2 (COVID-19 Virus)	10m	N/A	>99.9%	3-Log	CUBRC
	Staphylococcus aureus (Staph)	30s	N/A	>99.99%	4-Log	SGS
Gen 2 RapidClean UVC Box	Escherichia coli (E. Coli)	30s	N/A	>99.99%	4-Log	SGS
	SARS-CoV-2 (COVID-19 Virus)	Зm	N/A	>99.9%	3-Log	CUBRC



Testing for SARS-CoV-2 was preformed at the CUBRC's CDC-permitted Biosafety Level 3 facility located at the University of Buffalo.



Before and After 10 seconds using **VitaLight™** UVC Sanitizer in a 3rd party laboratory.



Testing for Staphylococcus aureus and Escherichia coli was preformed by SGS, the world's leading inspection, verification, testing, and certification company.



Before and After 15 seconds using VitaLight™ UVC Sanitizer in a 3rd party laboratory.

## DON'T TRUST YOUR HEALTH TO INFERIOR PRODUCTS

Call Us 1-800-316-2532 info@vitalight.com Learn More at vitalight.com

