

# MSA Advantage® 200LS and Advantage 290 Respirators



## Donning



1 - Loosen all the straps.



2 - Pull the neck strap over your head and place it around your neck.



3 - Place the top portion of the facepiece on the bridge of your nose and swing the bottom of the facepiece inward.



4 - Pull the cradle headband over your head until it straddles the crown of your head.



5 - Pull the ends of the cradle headband straps to tighten the cradle around the crown of your head.



6 - Pull the ends of the neck strap to tighten the neck strap around your neck.



7 - Adjust the cradle headband and neck straps for a comfortable and secure fit.



### Negative Pressure Seal Check:

Place your palms over cartridges lightly.\* Gently inhale so that the facepiece collapses slightly and hold breath for ten seconds. The facepiece will remain collapsed while the breath is held unless there is a leak in the seal. Adjust the straps for a comfortable and secure fit and repeat if necessary. The respirator must pass this seal check before the respirator is used.

*\* If using Splash Guard Filters, depress and hold the center portion of the filter so it collapses slightly forming a seal.*

*Before use, please read and familiarize yourself with the Advantage 200LS or Advantage 290 Instruction Manual.*