

MERCURY User manual



Thank you for your purchase.

Please read the instructions carefully to know more about the watch.

Thank you for choosing our YOUNGGEAR smartwatch.

Thank you very much for purchasing and using our company's smart watch products.

You can have a comprehensive understanding of the watch's functions and easy operation methods by reading this manual. Our company reserves the right to make modifications to the content of this manual without prior notice. Some features that differ in the corresponding software versions are considered normal.

Key: Long press to turn on/off, click to wake up the screen when the screen is off, click on the dial interface to enter menu mode, and double-click on the menu interface to switch menu style.

Dial switching: Rotate the encoder to switch the dial.

Install the "Wearin" app

Before using this device, please download and install the "WearinAPP" on your phone. You can scan the QR code of the "Download App" on your device using the "Scan" function on WeChat or browser, and select the corresponding operating system on your phone to download and install it; You can also download and install by searching for 'Wearin' in app stores such as "App Store", "Google", and "AppStore".



Connecting a watch

Scan Code Connection: After downloading the app, enter the app, click on the top right corner, select the "Scan" function, press the button on the watch to enter the dial interface, slide to the right on the left side of the dial, click the "Connect Phone" shortcut button, and the QR code for connecting the phone will pop up.

At this time, use the app to scan this QR code and allow pairing.

If your phone is an iOS system, after completing this step, you need to connect the classic Bluetooth in Bluetooth based on the MAC address in the device (the MAC address can be viewed in "Setting About Watches").

Manual connection: After turning on Bluetooth on the phone, enter the app and click on the "Devices" page. Click on "Add Device" and then click on the icon that appears.

Finally, click on "Pair". At this time, the app will automatically search for nearby devices. You only need to find the name of the device you own and click to pair.

Connection status: After completing the above operation, slide down at the top of the device dial interface and you will see the "Bluetooth" icon filled in, indicating successful connection.

Selection of dial style

1. The device itself provides multiple dial options for you to choose from: when the device is lit, you can switch the dial style function by rotating the encoder.

2. The "dial market" in the app will give you more choices. When you connect to a watch using the app, you can download more styles of dials in the "Dial Market" of the app, and you can also delete the dials.

3. The app also provides the function of customizing the dial. You can customize the dial in the "Device" function of the app.

Operating instructions:



Sidebar: Swipe to the right on the left side of the dial interface to pull out the sidebar, providing multiple quick access functions.



Pull down panel: slide down at the top of the dial interface to pull out the pull down panel, which provides access to a variety of quick functions, and displays time, Bluetooth connection status, and power.



Notification: Slide up at the bottom of the dial interface to view the received notification message. Click on the corresponding message to view or delete it.

Menu page: On the dial page, press the side key to enter the menu page. After entering the menu page, double press the side key to switch menu styles. Press the side key to return to the main dial page.



Function page: Click on each application icon on the menu page to enter the corresponding function, right-click to return, and press the side key to return to the main dial.

Function Introduction:



Exercise: It includes various regular activities such as outdoor running, outdoor walking, indoor cycling, indoor running, indoor walking, and free exercise.

Heart rate: Hold the watch tightly against your wrist to measure real-time heart rate values. Historical measurement results can be viewed on the app.

Blood sugar: Hold the watch tightly against the wrist to measure blood sugar levels.





Oxygen saturation: press the watch close to the wrist to measure the blood oxygen value, and the historical measurement results can be viewed in the APP.

Blood pressure: By pressing the watch tightly against the wrist, blood pressure can be measured.

Activity Record: Record the day's exercise data, including steps taken, activity time, and calories.

Sleep: Check your sleep status every night, and sleep related data can be viewed in the app.



Al voice: After connecting to the app, the phone voice assistant can be called up through the AI voice function of the watch.

Information: After connecting to the app, the received notification will be displayed here.



Stopwatch: The watch supports stopwatch timing.



Timer: supports selecting minutes and customizing the countdown of the time.



Find my phone: After the device is connected to the phone, click this function to search for the phone.

Call records: After connecting to the phone, you can synchronize the phone's call records.

Frequently used contacts: After connecting to your phone, you can synchronize your phone contacts.

Dialing: After connecting to the phone, achieve a watch end call.

Settings: including brightness settings, screen rest time, do not disturb mode, sound settings, language switching, connecting phone, about watch, restarting, restoring factory, shutting down, and other functions.



Calculator: Provides calculation function, convenient and fast.



Taking photos: After connecting to the app, enter the app and click on the camera function on the watch to call up the camera function on the app, achieving remote control for taking photos; Clicking on 'take a photo' will activate the app's photo taking function. Clicking again will take a photo, which will be saved in the phone's system album.



23	12 12 12	en 24 14	09: 22 15		
22	20 16	4° 18	16 17 18 18	21 20	
2	powe m/	′s			
6.	idity: 7%	6			
Mond	ay 🔶		21		
Wedn	es 🔶		21	10	
Thurse	lay 🔶		20	10	
Friday	-		21	10	
Saturd	lay 🔶		22	10	
Sunda	у 🔅		22	11	
Monda	ay 🌥		23	14	

Female Assistant: Helping female friends record and manage important physiological cycles.

Temperature measurement: It can conveniently and quickly measure body temperature.



Time setting: You can independently set the time on the watch and choose whether to use a 24-hour system.

- Passcode: You can set the password. If you forget it, 8888 can be used to unlock it.
- Music: Can control the playback of music in the phone. Connect to 5.3 bluetooth, only support the mobile phone to play songs.

Shutdown: Enter to shut down the watch.

Dial settings & Watch faces:









Basic parameters

Product Name	Mercury		
Body material	Zinc alloy		
Battery capacity	220 mAh		
Screen size	1.43 in		
Screen type	AMOLED (466 X 466)		
Brightness	500 Nits		
Strap material	Silicon		
Bluetooth	5.3		

Kindly follow us here for more updates:



Thank you for your purchase and reading.

This product is not a medical device, and the health data and recommendations provided are for reference only and are not used as a basis for diagnosis and treatment. Operating instructions.

"Ensure that you fully charge the smartwatch before using it for the first time, to optimize its performance and maximize battery life."

Thank you for your purchase and reading