

HOW TO RESOLVE HEATED SEAT MALFUNCTIONING



1. Open the water valve and reset the unit







4 Plug the cord back



2. Check the setting in Remote control/ Side panel






- ① Push the nozzle cleaning button to check if the bidet seat is linked with the Side Panel(3000 Series), Remote control(4000/6000 Series)
- ② Set up the Seat temp setting to level 3 with the Side Panel(3000 Series), Remote control(4000/6000 Series)
- ③ Wait 3-4 minutes after setting up the seat temperature and check if it gets warm.



3-1. Open the bidet seat








① Unplug the cord

2 Close the water valve clockwise

3 Detach the hose from the unit



4) Push Section A(Located on the right side of the bidet seat) and slide the bidet seat out in the direction B




3-2. Open the cover base



Click for the Video Guide

① Unscrew the 2 screws at the back using a Philips head driver.




- 2) Put the flat screwdriver in the pointed location and lift it up to detach the base from the cover base.
- Make sure not to open the cover base fully so the wires inside do not get damaged.




3-3. Check the seat harness








2) Check the connection with the MAIN PCB and the seat wire



- (3) Check the connection with SIDE IR harness
 - **X** Applies only to 6000 Series



3-4. Close the cover base







Video Guide

1 Put the harness linked with the seat on the A side 2 Push the unit towards the direction shown in the and close the cover base

photo



(3) Check whether the cover base is assembled perfectly. If you heard clicks, it's perfectly done.




4 Screw the 2 screws back using a Phillips head driver.




3-5. When you have difficulty closing the cover base



① Flip the bidet seat so you can see the under the bidet seat.



③ If not, please use a flat driver to make sure that the base goes inside the cover base.




2) Check if the base goes inside the cover base



4 Push the unit towards the direction shown in the photo



3-6. Attach the bidet seat



① Slide the bidet seat to the installed base bracket



2 Connect the hose



③ Open the water valve



4 Plug the unit back