M3 eMeetLink User Manual

EMEET OfficeCore M3

Device settings

Firstly, connect the device to the computer via USB cable.

Open the eMeetLink software and enter the setting interface.

1. Bluetooth name

You can change the Bluetooth name of your device to make it easier to find on the available list.



2. Standby time

You can decide how long the device shuts down after you stop using it.



3. Lighting

You can turn on/off the DOA function to decide whether the DOA light will show on the device according to your needs.



4. Switch

You turn on/off the VoiceIA Intelligent cancellation, Prompt tone, Bluetooth, Bluetooth reconnection after device turning on functions to decide whether they will show on the device according to your needs.



5. Never

You can drag the slider to adjust the intensity of voice pickup.



6. Restore Default Settings

After restoring default settings, all operating settings will be restored to factory mode.



Settings

In this setting interface, you can change the language according to your need.

Check your eMeetLink software version and update it.

8		-		×
	Set up			
•	Language selection	English	>	
۰	Software update			
0	Software Version		4.0.3	
*	Detect new version	Check for up	pdates	
	Software update notification			
	Auto update			
	O Notification			
	Allow popup			

Support

1. Feedback

Write your feedback here to get EMEET customer service support.

Feedback FAQs User Manual Compatible device Contact Question type: Device Name: Please select Please select Please select Problem Description: Please enter Please enter Please select Please select	Feedback FAQs User Manual Compatible device Contact Question type: Device Name: Please select Please select Problem Description: Please enter Please enter Submit Cancel						-	
Question type: Device Name: Please select Please select Problem Description: Please enter	Question type: Device Name: Please select Please select Problem Description: Please enter Submit Cancel	Feedback	FAQs	User Manual	Compatible device	Contact		
Please select Please select Problem Description: Please enter Standa Cancel Cancel<	Please select Problem Description: Please enter Submit Cancel	Question type:				Device Name:		
Problem Description: Please enter Solumit Cancel	Problem Description: Please enter Submit Cancel	Please select			\sim	Please select		
Please enter	Please enter Submit Cancel	Problem Descri	ption:					
Submit: Cancel	Submit Cancel							
Subint Cancer		Submit C	ancel					

2. FAQs

There are some common questions for your reference.



3. User Manual

Click the device to enter EMEET official website and get the user manual.



4. Compatible device

							-	×
Feedback	FAQs	User Manual	Compatible	device	Contact			
🙁 camera			·					
Capsule	C950	C955	C960	C965	C970	C970L	C980 Pro	
0								
C990	Jupiter	Nova						
Microphone								
MO	M2	M220	M2 Max					
Earnhone	IVIZ	WILLO	WE WOX	Luna	Luna Lite			
0								
HS100								
C Accessory								

5. Contact info

					-	
lback	FAQs	User Manual	Compatible device	Contact		
Telephone						
+1 888 959 53 81 800805195 00 8338 051 J	320 Mon-Fri 9: 55 月-金 10:00a 周—-周五 9:00a	:00am - 5:00pm (EST) am - 6:00pm (JST) am - 5:00pm (BJT)				
Official we	bsite					
nttps://www.en	neet.com					
E-mail						
Support: suppo	ort@emeet.co	m				
Marketing: ma	rketing@eme	et.com				