

Chef-Mate Kitchen Scale

Model : KS 63



Sensing **Health** Everywhere



Healthsense is a proud Indian brand creating quality products idealised and conceptualised for India and manufactured by exclusive overseas partners.

www.healthsense.in

Connect with us @healthsenseindia



Manual Instruction

The scale is intended for household use only. Not legal for trade. Please read the instructions carefully before use.

ADVICE TO THE USER

This product is a sensitive electronic instrument and it may be affected by radio transmitting devices being used in close proximity (such as mobile phones, radios, radio model controllers and some microwave ovens).

If the appliance exhibits symptoms such as errors or erroneous data, try moving the product away from the source of interference or switching off that source of interference while you are using this product.

FEATURES & SPECIFICATIONS

- | | |
|--------------------------------------|---|
| 1. Equipped with precision sensors | 5. Three weight units - g/oz/lb:oz |
| 2. Max capacity : 5kg or 5000g | 6. Two volume units - ml(milk)/ml (water) |
| 3. Graduation : 0.001kg/1g/0.1oz/1ml | 7. Low battery "Lo" indication |
| 4. Touch ON/OFF & Tare buttons | 8. Over-load indication "EEEE" |

WARNING!

- Your new scale does not require any specific maintenance.
- Handle your scale with care, as it is a precision instrument, i.e. never expose it to extreme temperatures, moisture, winds, dust and direct sunlight. Do not drop the scale or knock it.
- Keep your scale away from sources of heat.
- Clean your scale with a damp cloth, never use abrasives or solvents.
- Do not overload the scale.
- Do not open the scale. In the event of opening or tampering the guarantee becomes invalid.
- Refer to authorized service centers for maintenance.
- See that no liquids penetrate inside the scale. This appliance is not watertight. Do not store or use the scale in a damp room with humidity above 85%. Make sure that the scale does not come into contact with water or other liquids as this may cause corrosion and jeopardize the precision of the scale.
- Keep the appliance out of the reach of children

BATTERY INSTALLATION/REPLACEMENT

The scale operates with replaceable AAA batteries.

- Insert into the battery compartment located at the bottom of the scale 2xAAA battery with the correct polarity.
- When the batteries are discharged the display will show either "LO". Remove the batteries if the scale is not to be used for a long period of time.

CAUTION

- This scale is not waterproof. Do not expose to moisture
- Make sure your scale is at room temperature, and on a stable horizontal surface free of vibration.
- Store your scale in a clean, dry location. Dust, dirt, and moisture can accumulate on the weighing sensors and electronics causing inaccuracy or malfunction
- Gently place all items to be weighed. Do not drop items onto the weighing platform

OPERATING INSTRUCTIONS

- Place the scale on a flat surface.
- To switch on press ON/OFF/TARE key "Φ"
- To switch off press ON/OFF/TARE key "Φ" for 3 seconds
- Unit selection: Press "Unit" key after the LCD is returned to zero to select preferred unit
- Now place item onto weighing platform
- Weight is displayed
- If you wish to use a container on the scale you can either place it on the scale before the scale is turned on, or after the scale has been turned on and is showing "0" (g/oz/ml(water)/ml(milk)/lb:oz) Place the container and press "TARE". This will zero the scale to enable you to weigh your ingredients in the bowl. Please be aware that the weight of the container will affect the total capacity of the scale, therefore if the bowl weighs 1000g, then the capacity for weighing will be reduced to 4000 grams (see "overload" notes below)
- Overload: When the weight is less than 5250g, it can measure accurately. When the weight is more than 5250g, it exceeds the Max weight range, LCD will display overloading error (see Fig 1)



Fig 1

TARE FUNCTION

The tare function allows you to reset the scale to zero at any time and to weigh different ingredients without removing goods already weighed

- Press the [ON/OFF/TARE] button located on the front panel. The display will show "0.0".
- Weigh the first ingredient.
- Press the [ON/OFF/TARE] button again to zero the display (if you press for a prolonged period of time the scale will turn off.)
- Weigh the second ingredient. Repeat process if desired.
- If you wish to use a container on the scale you can either place it on the scale before the scale is turned on, or after the scale has been turned on and is showing "0" (g/oz/ml(water)/ml(milk)/lb:oz). Place the container and press "TARE". This will zero the scale to enable you to weigh your ingredients in the bowl. Please be aware that the weight of the container will affect the total capacity of the scale therefore if the bowl weighs 1000g, then the capacity for weighing will be reduced to 4000 grams.

WARRANTY & SUPPORT

Entitle yourself for the 1 year HealthSense warranty by registering your purchase and easily reach us to submit your product related issues & queries, when you follow these hassle free ways.

SCAN - For Warranty Registration



(Must register within 30 days from date of purchase)

SCAN - To File Complaint



(Fill & submit form if you are facing any product related issues)

* For detailed warranty terms please visit the link : www.healthsense.in/warranty-terms
* For additional support : Mail us at support@healthsense.in or Call us on : 080-41262836