

# Quick Start Guide

Begin with clean: water, tub & filters

## NATURE 2 HOT TUB SUPPLIES KIT



1



### MPS 3-in-1 Test Strips:

Tests water balance Total Alkalinity (TA), pH, and Monopersulfate (MPS-Oxy Spa). Fill the spa with fresh water, then test for TA & pH. Note results. Re-test for MPS later.

2



### Alkalinity & pH Up:

Raises low pH and Total Alkalinity (TA). If TA tests below 80ppm, add 1 heaping capful per 400 gallons to raise in 10ppm increments. Circulate water 30 minutes, retest.

3



### Alkalinity & pH Down:

Lowers high pH and Total Alkalinity (TA). If TA tests above 120ppm, add 1 level capful per 400 gallons to lower in 10ppm increments. Circulate water 30 minutes, retest.

4



### Hardness Test Strips:

Tests for Total Hardness of spa water. Nature2 recommends a minimum of about 200ppm.

5



### Calcium Hardness Booster:

Raises low Hardness. If low, 1 level capful in 400 gallons increases calcium about 10ppm. Pre-dissolving recommended. Circulate water 30 minutes, then retest.

6



### Metal Stain Preventer:

Prevents staining and corrosion from dissolved metals. Add bottle contents on startup and with each water change.

7



### Chitosan Natural Clarifier:

Promotes crystal clear water naturally. Add 1 oz. at startup and weekly per 300-500 gallons.

8



### Nature2 Mineral Sanitizer:

After balancing spa water, install into filter cartridge per package directions. (Lasts 4 months).

9



### DiChlor Shock:

Activates the Nature2 Sanitizer. Add 1.5 tablespoons per 250 gallons spa water. Also used to superoxidize spa after heavy use. Pre-dissolving in plain water recommended.

10



### Oxy-Spa Chlorine-Free Shock (MPS):

Helps to maintain water quality. Add 2 oz. (1 level capful) for up to 500 gallons spa water after each use. May be tested periodically with MPS Test Strips.

11



### ZorbO Oil Scum Absorber:

Hi-tech polymer with flow-thru design wicks-up oily film and inanimate scum. Float in hot tub. Replace every 3 to 4 months.

(800) 823-3638 | Mon-Fri 6 AM-5 PM Pacific

Rev. 10-05-22



KT1005Q