Product introduction and features

This is a smart and stylish wearable device that makes your life and communication safer, more comfortable and more convenient. Has the following features:

- * Dual-core super-computing audio chip, cinema-quality surround sound
- * Professional 5GTQ directional sound, open immersive listening, protect your hearing
- * One-button switching between indoor/outdoor mode makes listening more comfortable
- * Professional glasses industry frame, comfortable to wear

Frame material	TR 90	Microphone	Silicon wheat, call noise reduction
Lens	Replaceable	Speaker	φ16 custom speaker
Lens material	TAC polarized	Transfer Protocol	SBC AAC
Bluetooth	5.0	Connection distance	10 M
Battery capacity	110mA	Signal to noise ratio	-84dBV+A
Charging time	1.2Hr	Bluetooth protocol	HFP 1.7 HSP 1.2 A2DP1.3 AVRCP 1.6 SPP 1.2. PBAP 1.0
Length of use	Over 5Hr	Resolution	-90dB 1K
Standby time	40Hr(Bluetooth connection status)	Operating temperature	0-45°C

Diagram Speaker sound hole Charging line interface direction Charging interface Speaker sound hole Power button Indicator light Microphone Function button

Instructions

Power button

Power switch / Indoor and Outdoor mode switching

Function button

- 1) Pause/play music, short press function key
- 2 Answer / hang up the phone, short press
- ③ Refuse to answer the call, long press for 3 seconds
- (4) Double-tap to wake Siri and Google Assistant

Indicator light

- ① Charging: The red light is always on. When the battery is fully charged, the indicator light is off.
- ② On/Off: The indicator lights are red and steady for 2 seconds, then enter the Bluetooth pairing status.
- 3 Bluetooth to be paired: red and blue flashing Pairing success: light blue slowly flashing
- Working status: the indicator light flashes slowly in blue
- ⑤Low battery tone

Charging

- 1) Pay attention to the correct charging line direction, it takes 1.2 hours to fully charge.
- 2 The charging power is 0~99%, and the red indicator light is always on.
- The battery is fully charged and the indicator is off.

Bluetooth connection

(1)connection

- Long press the power button 2s to turn on, the indicator light blue flashes
- 4s automatically enters the pairing state, and the indicator light changes to a red-blue flashing state. Turn on the phone Bluetooth, search for the device name (ROKiT EYE Q) and connect.
- The pairing is successful and the indicator light flashes slowly.

2) Restore connection

- After the glasses are turned on, the glasses automatically connect to the last connected device. If the last connected device is not within the Bluetooth detection range, the glasses enter the state to be
- There is no Bluetooth connection for 3 minutes, and the glasses are turned off.

3 Cancel all connections

In the off state, long press the power button 4s glasses to enter the state to be paired, the indicator light flashes red and blue

Sound prompt function

Glasses have the following function sound prompts: Power on/off, Bluetooth connection successful, outdoor/indoor mode switching, low battery. Note the difference.

Precautions

- ①Since this product is not waterproof, do not use a faucet to rinse. Do not put it in an ultrasonic cleaner for cleaning
- ②Lens cleaning method: Spray the special lens cleaning agent mirror surface, then use the suede-absorbing glasses cloth and wipe it clean in the same direction.