URB/\N



FUSION

Packed Box Content

- · Smart Watch With Strap Magnetic Dock Charger

Getting Started:

Download the Fitcloudpro App to sync



- Long Press the power button on your smart watch for 3-5 seconds to power-on
- Open the Fitcloudpro App on your mobile phone and fills your personal details on the App

Search for Fusion on the app


(Make sure Bluetooth on your phone is switched on) Click on Fusion to connect and pair successfully.



Turn your smart watch on/off by long pressing the power button for 3-5 seconds

Charging URBAN Fusion

Please charge your smart watch first before using it for the first time Use the magnetic charger provided in the box Use genuine URBAN 2-pin magnetic charger only



How to sync with Fitcloud Pro App



Fill your details for the

· Use only 5V/2A Adapter for

charging purpose.

Home Device Me

Successfully Connected



Click on your device in the App Successfully Connected



n on your smart watch will light up, indicating onnection is successful

Activating the Bluetooth Call Feature

Step 1: After connecting the smart watch with Fitcloud pro App, you need to go to the Bluetooth settings of the phone and pair the watch with your phone for Bluetooth calling and phone music function The process of connecting the Bluetooth calling feature will be similar to the

wireless earphones connection of your phone; The process of connection will be different for iOS and Android devices After the connecting with App. It will remind you to connect phone BT call function by connecting mobile phone Bluetooth in phone setting menu.





Bluetooth setting list to "FUSION" in "MY DEVICES" list

For Andriod



FUSION" Please Pair it

Bluetooth, It will show

"FUSION"



If your smart watch connected After click to pair, then you will with the App successfully, App see the device name "Audio will display "Pair with Audio - FUSION" is in phone Bluetooth list

Step 2 : Now your smart watch is ready to be used for BT calling feature You can go to the dialer pad and start calling from your URBAN Fusion





Dial Pad

On standby swipe left on your smart watch to enter the access different exercise modes

- Then select on the sports mode you want to start
- If you want to add the other fitness activities click the (+) icon on your smart watch to add the mode in your shortcut



General Sports

• Long press the screen for 3 seconds on standby to see the watch faces; swipe left and right to scroll through different watch faces

You can download more watch faces from the app and even customize as per your requirement





 Choose the menu style as per your convenience - honeycomb, list, grid. parallel, surface crescent, full moon, helm designed for the easy switch and smooth user experience.



Menu Style







Voice Assistant

• To access Voice Assistant from your smart watch, Swipe 7 times towards right on standby

Note: The phone need to be connected with Bluetooth and App for activating this feature







Swipe Down 🗸 🕇 Swipe Up













• Swipe down on standby to view your smart watch's control center



Bluetooth connectivity

Adjust the brightness of the screen

Instruct the Bluetooth connection status

Do not disturb If turn on, phone calls and notifications will silent

Brightness Settings Power Save Mode

If turn on, vibrations and quick view will be turned off, and brightness will be turned down

Menu Style Setting Tap to enter into menu style selections

Phone Call Mode Turn to enable watch can connect with phone Bluetooth

Tap to enter into setting center







Steps Count / Distance / Calorie Count

· Just swipe right on your smart watch to enter step count feature on your smart watch

 To track and ensure good health you can monitor data like step count, distance, and calories burnt over your phon via Fitcloudpro App.







- · Swipe twice towards right on your smart watch to enter the sleep monitor feature on the smart watch.
- To track your data i.e. light sleep, & deep sleep analysis and number of hours

 Swipe four times towards right on your smart watch to enter the blood





 $\bullet\,$ Wait for 5 to 10 seconds to get the detailed analysis of you heart rate.





pressure feature • Wait for 5 to 10 seconds to get the detailed analysis of your blood pressure.





• Wait for 5 to 10 seconds to get the detailed analysis of your blood oxygen.



Weather Forecast Swipe 5 times towards right to enter the Weather Updates feature on your

 Just connect your smart watch with your smart phone to get the weather updates for a week easier on your smart watch.





Breathing



This helps to track the time frame for any given activity.



• Swipe three times right on your smart watch to enter the heart rate feature

• Swipe four times towards right to enter the Spo2 feature on your smart watch to



 After watch connecting with App.Tap the shutter icon to remote control the camera of your phone to take photos.



Sedentary Reminder

 Don't mark always on the calendar the smartwatch will remind you the Sedentary Reminder occassionally.



This sets a preset timer for the user to track and given time line



Message Notifications

• If you sync your smart phone with **Fusion** you can receive notifications straight from your wrist



Swipe down from main interface to enter into control center and tap





Drink Water Reminder

Tap "Display" to enter and set display. Set Auto Sleep Time Menu View



will remind you to drink water based on what you set via Fitcloudpro App.

• Tap "About" to check watch version and QR Code.

• It is forbidden to throw this product into the fire to avoid an explosion. The battery life varies according to the environment and usage mode • If you set Drink Water Reminder function on Fitcloudpro App watch

Precautions for charging the smart watch



Daily maintenance of the watch and precautions

by misuse or improper use are not covered under warranty • Don't use detergents such a soap, hand sanitizer or both foam for cleaning

alkaline solutions and chemical reagents. Damage or defects caused

to avoid chemical residues from irritating the skin or corroding the devices.

Company reserves the right to modify and improve any of the function.

• This product is not a medical device. The watch and its application should not be used for diagnosis treatment, or prevention of disease. If you want

to change your habits such as exercise and sleep, please consult qualified

medical personnel first, in case if you are suffering from serious casualties,

Avoid overnight charging





