



URBAN
BLUETOOTH Calling
NEXUS M
USER MANUAL

Unbox Your Content

- Smartwatch with Strap
- Bluetooth Charging Cradle
- Thank You Card
- Warranty Card

Unboxing Instructions

Download the DeFiX App on your phone



- Long Press the button on your smart watch for 8 seconds to power on
- Turn on the Bluetooth on your phone
- Open the DeFiX App on your mobile phone and fill your personal details in the App
- Push on "Nexus M" on the app
- Click and install Nexus M Smartwatch


Connect with your phone

- Android system: Scan Google Play to download and install DeFiX App. Or Scan QR Code to download.



Charge the Smart Watch

- The smartwatch must be charged before using it. It takes 2 hours to be fully charged.
- Use only USB-A Adapter for charging purpose.



Switch on your Smart Watch

- To turn the watch on/off
- Long press side button for 3-5 seconds



Sync the Smart watch with DeFiX App



Click on your device in the App



Successfully Connected

Adjusting Bluetooth Call Feature Here to connect



Step 1: After connecting the watch to the DeFiX app, you need to go to the Bluetooth settings of the phone and pair the watch with your smartphone as the watch uses your phone for Bluetooth calling function and phone music function.

For iOS:



Click to "ADD" to search for Nexus M



Click on your device in the App



Successfully Connected

After the connecting with App, it will remind you to connect phone BT call function by connecting mobile phone Bluetooth in phone settings.



Step 1: After connecting the watch to the DeFiX app, you need to go to the Bluetooth settings of the phone and pair the watch with your smartphone as the watch uses your phone for Bluetooth calling function and phone music function.


For iOS:



Click to "ADD" to search for Nexus M



Click on your device in the App



Successfully Connected


If you can't connect with smart Bluetooth, please check the follow:



Then try to connect with phone Bluetooth in below steps:



For Android:



If the watch not connect with App automatically, App will display "Pair with Auto - NEXUS M" Please Pair it.



After click on Pair, then you will see the device name "Nexus M" in "My Bluetooth list"



Step 2: Go back to the watch and enter phone call mode. To make phone calling, please make sure that the phone connection (Please check the mobile phone is in "My Phone List" mode to ensure Bluetooth is connecting a phone when when you see Bluetooth calling function).





Phone defaults to watch

Sports Mode

- Swipe left on your smart watch to enter the sports interface.
- Swipe left on your smart watch to see the sports mode.
- If you want to add the sports mode, please click on the "Add" icon on the smart watch to add the sports mode you want.





Phone defaults to watch

Watch Face

- Press the crown for 5 seconds at the smart interface or tap "Watch Face" function icon face to enter the watch face mode in your watch.
- If you have designed the watch face to watch and DIY select face from App.




Phone defaults to watch

Wake Assistant

- Swipe left 7 times towards right to enter the Wake Assistant feature on your smart watch.
- Use Gestures your smart watch with your smart phone to get the watch done easily by connecting with a third smart watch.




Phone defaults to watch

Control Center

Swipe down to view watch control center:



Phone defaults to watch

Function Navigation

- The screen can be navigated by swiping left / right / or clicking upstream.



Phone defaults to watch

Multi-Color Face





Phone defaults to watch

Sleep Monitor

- Swipe right to view the left side of the Nexus M smart watch to enter the sleep monitor feature on the smart watch.
- To track your sleep, light sleep, deep sleep and number of hours you sleep etc.




Heart Rate

- Swipe three times right on your smart watch to enter the heart rate feature on your smart watch.
- Wait for 30-60 seconds to get the detailed analysis of your heart rate.




Blood Pressure

- Swipe five times towards right on your smart watch to enter the blood pressure feature.
- Wait for 5 to 10 seconds to get the detailed analysis of your blood pressure.




Blood Oxygen

- Swipe four times towards right to enter the SpO2 feature on your smart watch.
- Wait for 30-60 seconds to get the detailed analysis of your blood oxygen.




Weather Forecast

- Swipe six times towards right to enter the Weather Update feature on your smart watch.
- Each weekend, your smart watch with your smart phone to get the weather updates for a week ahead on your smart watch.




Music Function

- Enter into Bluetooth to take Bluetooth music.




Stop Clock

- This is used to track the time frame for any given activity.




Alarm

- Set an alarm on your smart watch to remind you of the given.




Shower

- After watch connecting with App, the shower icon to remote control the shower of your shower to take shower.




Exercise Records

- You can check the exercise status in specific watch mode.




Physiological Cycle Reminder

- Don't mark always on the calendar the Nexus M smart watch will remind you the physiological cycle assistance.





Calculator

- The new feature lets you access the calculator on the watch face!




Message Notification

- If you use your smart phone with Nexus M, you can receive notifications straight from your smart.




Settings

- Swipe down from watch interface to enter the smart control and "Settings" feature on the smart watch to use the smart system.




Display Settings

- Tap "Display" to enter and set display. Set Auto Screen Off like the Brightness, Watch Face.




Reset Settings

- Tap "Settings" on Nexus M smart watch to reset the Bluetooth connection.




Watch Status Reminder

- Tap "Status" to enter and set status. Set Auto Screen Off like the Brightness, Watch Face.

System Settings

- Tap "System" to reset the Nexus M, it will display the status history.

Always

- Tap "About" to check watch version and QR Code.

Watchface Loading Reminder

- Tap "Watchface" to enter and set watchface. Set Auto Screen Off like the Brightness, Watch Face.

Goal Achieved Reminder

- Watch will remind you the goal you set via DeFiX App for smart watch.

Tips

- Daily maintenance of the watch and accessories
- The watch is not resistant to extreme heat (such as heater, oven) and should be used in a well-ventilated area. Do not use the watch in extreme cold or hot environments.
- Don't use the watch in a humid environment, such as a shower, or in a high humidity environment.
- Don't use the watch in a magnetic field, such as a MRI machine, or in a high magnetic field environment.
- Don't use the watch in a high electromagnetic field environment, such as a power line, or in a high electromagnetic field environment.
- Don't use the watch in a high electromagnetic field environment, such as a power line, or in a high electromagnetic field environment.

Precautions for charging the smart watch

- Use the original charging cable and power supply.
- Don't use the charging cable in a high humidity environment.
- Don't use the charging cable in a high temperature environment.
- Don't use the charging cable in a high electromagnetic field environment.
- Don't use the charging cable in a high magnetic field environment.



www.gourban.in