URB/\N





USER MANUAL

• Long Press the button on your smart watch for 3-5 seconds to power-on

Sync the Smart watch with Da Fit App . Turn on the Bluetooth icon's on your phone

the App Search for Pro M on the app

Click and paired Pro M Successfully.



Or Scan QR Code to download.



Download App from Watch QR Code App in smartphone





Android system, select Google Play to download and install Da Fit App. Note: Your mobile phone must support android 5.0 less IOS 8.0 or above.







Fulfill your data when first use Da Fit App Add device

SPO2





Click on your device in the App Successfully Connected





Click to "ADD" to search Pro M

100% REMOVE



Bluetooth Calling

How to connect Step 1: After connecting the watch to the Da Fit App, you need to go to the Bluetooth settings of the phone and pair the watch with your phone and pair

connection for iOS and Andriod is different as well. Please check the following



with 2 inbuilt games

After the connecting with App, It will remind you to connect phone BT call If you can not connect with phone Bluetooth, please check as below. function by connecting mobile phone Bluetooth in phone setting menu.



Bluetooth setting list to Bluetooth, It will show "Pro M" in "MY DEVICES" list search and connect





Then try to connect with phone Bluetooth as above steps





calls, check records and interface contacts (Please keep the music player is









107 Sports Mode

- Scroll left on your smart watch to see 19+ sports mode If you want to add the other fitness activities click the (+) icon









Add Sports Mode

Phone contacts in watch

Inbuilt Watch Face

- - You can download the watch face to watch and DIY watch face from App.





Choose the style you like, honeycomb/list/grid/parallel/surface crescent







- · Just Connect your smart watch with your smart phone to get the works done easier by communicating with your smart watch.



Voice Assistant




• Swipe left from main interface to "Add Components" interface and tap "+" icon to add new functions to main interface.



Rotating Crown Functions

Swipe down to view watch control center











Control Center



Control Center





Power Save Mode





Function Navigation



Setting Tap to enter into setting center

• This screen can be navigated by swiping left / right or swiping up/down.














If turn on, vibrations and quick view will be turned off, and brightness will be turned down

Phone Call Mode

Turn to enable watch can connect with phone Bluetooth

To track and ensure good health you can monitor data like step count, distance, and calories burnt over your phon via Da Fit App.



Sleep Monitor

monitor feature on the smart watch.













Swipe twice towards right on your Pro M smart watch to enter the sleep

you slept etc.



Swipe four times towards right on your smart watch to enter the blood

pressure feature · Wait for 5 to 10 seconds to get the detailed analysis of your blood pressure.













After successfully connected with phone Bluetooth, the watch phone call interface will display.















Swipe left on your smart watch to enter the exercise feature.

on your smart watch to add the sports mode you want

Once you complete your workout you can track your fitness

Press the screen for 3 seconds at the main interface or tap watch face function interface to enter in to watch faces in built for your selection





fullmoon/helm designed for the easy switch and smooth user experience.





Add Components





Reset Settings

System Settings



Use only 5V/2A Adapter for charging purpose.

Rotate Button - Up button with rotate function to select.

Charge your Pro M for 2 hours before using Just Charge your Pro M with

the help of magnetic charging dock which is available in the box





Watch Status Reminder

Drink Water Reminder

Watchface Loading Reminder

to drink water based on what you set via Da Fit App.





Main Inter Face











Steps Count / Distance / Calorie Count Just swipe right on your smart watch to enter step count feature on your smart watch



Heart Rate

on your smart watch · Wait for 5 to 10 seconds to get the detailed analysis of you heart rate.



Blood Pressure





Weather Forecast smart watch







Inbuilt Games • Swipe three times right on your smart watch to enter the heart rate feature • Swipe five times towards right to enter the Spo2 feature on your smart watch • Add some fun to the monotonous life and play games happily as it comes













Lap Start

Set alarms and let your watch vibrate to remind you of the alarm.





07:00 × zz









the camera of your phone to take photos.



Flash Light



Never be scared in the dark again. The watch supports flash lights.









Physiological Cycle Reminder • Don't mark always on the calendar the Pro M smartwatch will remind you the physiological cycle occassionally.




· This sets a preset timer for the user to track and given time line



This new feature lets you access the calculator on the watch itself.

Message Notifications







"Settings" icon to enter into setting list to set the watch system.





Display Settings Tap "Display" to enter and set display. Set Auto Sleep Time Menu View Brightness, Watch Face.



Call Alert Settings



Tap "Lower Power Mode" to turn off the vibration, quick view and turn down

Lower Power Mode Settings

the brightness.



Tap "About" to check watch version and QR Code.

Tap "System" to restart the watch, shut down or restart the data instantly.







• Watch will display "Loading" when you upload new watchface from App to

to avoid chemical residues from irritating the skin or corroding the devices. Disclaimer

Precautions for charging the smart watch

Don't use fast charging technologies Use: 5V 2A adapter only

 \bullet Ending a charge at 80 – 90 % is better for the battery than topping up to

Avoid overnight charging

by misuse or improper use are not covered under warranty

· This product is not a medical device. The watch and its application shoul not be used for diagnosis treatment, or prevention of disease. If you want change your habits such as exercise and sleep, please consult qualified medical personnel first, in case if you are suffering from serious casualties, Our company reserves the right to modify and improve any of the functio

The watch is not resistant to erosive liquids such a seawater, acidic and

alkaline solutions and chemical reagents. Damage or defects caused

· It is forbidden to throw this product into the fire to avoid an explosion. The battery life varies according to the environment and usage mode.



























































