FINISHED PRODUCT AFTER SPACER IS PLACED **ON TOP RIGHT OF THE LIGHT FIXTURE** 

## LED **AUDIO LIGHT BULB**




**INCLUDES ONE WHITE** SPACER AND SCREW

## **HOW TO INSTALL SPACER**

Installation of the spacer is quick and easy. Remove the screw from the top right of the light fixture extension. Once removed place the new screw through the white spacer (as pictured in photo A). Place the screw with the spacer attached back into the light fixture and screw back in. DO NOT OVERTIGHTEN! This will allow your new LED Audio Light Bulb to be supported by the light fixture. If you have any questions please contact our customer service team at 563-359-3881 ext, 7381 or 7344.





SPACER INSTALLED



## The Original Patented Far Infrared Health Sauna

## SPACER AND LIGHT BULB INSTALLED

