

SMART AUDIO GLASSES



User Manual

Disclaimer

First of all, thank you for using our products! Please read this manual before using and use this product correctly. This product due to upgraded specification subject to change, without prior notice.

Open-ear smart audio glasses, this product is a bluetooth speaker with stereo function, easy to operate, stylish and practical, easy to carry.

Packing list











Warm warning: The image shown here is indicative only. The actual product may differ.

Specification

Color	Black	
LENS	Black	
Material	Nylon	
SIZE	52*18*149	
Lens material	Polycarbonate	
BT protocol	5.0	
Charge time	2H	
Work time	5H	
Standby time	180H(Bluetooth connected)	
Battery	110mAh	
Charge voltage¤t	DC5V 160mA(MAX.)	
Speakers	Dual speakers,Stereo	

- Qualcomm 3024 Bluetooth 5.0 chip.
- Left and right dual speakers, directional playback, true stereo sound.

Operation instructions





Tips: chagre time:2-3 hours. Battery will be discharged automatically is left unused over a long period of time.

Operation instructions

	Operating	Glasses tone	illuicator activity	
On/Off	Press button for 3 seconds	Power on	Hold on for 1 seconds	
	Press button for 5 seconds	Power off	Hold on for 1 seconds	
Pairing& Connection	In the off satus Press button for 5 seconds	Pairing	Flash continuously	
	In the off satus Press button for 10 seconds	Clear away paired device list	Flash continuously	
	While power on and the phone is disconnected	Fast blinking white		
	while power on and the phone is connected	Slow blinking white		
	The phone is Reconnnected	Connected	Slow blinking white	
	Status	Glasses tone	Indicator activity	
Charging& Alarm	Low-power alarm	Battery low	LED light flash twicein every 2 seconds	
	Low power off	Power off	Hold on for 1 seconds	
	Charging	Solid white		
	Charging completed	Slow blinking white		
	Button operating	on operating Function		
Play music	Press once Play/Pause		Pause	
	Double-Press	Skip forward		
	Triple-Press Skip backward			
Call funcions	Press once Answer a call			
	Double-Press	End a call		
	Triple-Press	s Last nubmer Redial		
During the call	Press once	Press once Answer incoming call and end the current call		
	Double-Press			
Voice Assistant	Double Press the button while connecting with the smartphone.			



http://www.hifuturegroup.com/



HENZHEN FUTURE ACCESS TECHNOLOGY CO.,LIMITED.Explore more at www.hifuturegroup.com © All Rights Reserved SHENZHEN FUTURE ACCESS TECHNOLOGY CO.,LIMITED.Explore more at www.hifuturegroup.com © All Rights Reserved EN FUTURE ACCESS TECHNOLOGY CO., LIMITED. Explore more at www.hifuturegroup.com © All Rights Reserved SHENZHEN FUTURE ACCESS TECHNOLOGY CO., LIMITED. Explore more at www.hifuturegroup.com © All Rights Reserved

Customer service

For more product information please visit www.hifuturegroup.com Contact your local authorised dealer/ customer service.

email: info@hifuturegroup.com

Service hot line: +86 755 8256 1018

Limited Warranty

Note: Disassembling device voids warranty Note: Liquid submersion voids warranty

Tips

- 1. Please read the instructions carefully before using this product and keep this manual for further use.
- 2. For the first time, please fully charge this glasses.
- 3. Battery will be discharged automatically is left unused over a long period of time (more than two weeks), charge it before using.

Warning

- 1. Do not dismantle or repair this product for any reason, as this may result in fire, electronic breakdown or even complete damage to the product.
- 2. Do not place the device in an environment where the temperature is too low or too high (below 0 ° C or above 45 ° C).
- 3. Do not get the product wet with liquid or immerse in liquid.
- 4. Do not expose the glasses to the sun for a long time, otherwise it will be easily deformed and broken.

Important safety information I

- 1. Please read all safety information before using this equipment to ensure correct and safe use.
- 2. Use of a power source, charger or battery that is not approved by this manufacturer may cause fire, explosion or other hazards.
- 3. Use accessories approved by this manufacturer and compatible with this model. Please use the device within the temperature range of 0 °C ~ 35 °C, and store the device and its accessories within the temperature range of -20 °C ~ 55 °C. When the ambient temperature is too high or too low, it may cause equipment failure.
- 4. If the device uses a non-removable internal battery, do not replace the battery yourself to avoid damaging the battery or device. The battery can only be replaced by an authorized service center.
- 5. Please charge according to the charger specified by the manufacturer. Using a charger with other voltages may cause leakage, fire or damage to the device and charger.

Important safety information II

- 6. If charging is complete, disconnect the charger from the device and unplug the charger from the power outlet. Do not charge more than 12 hours.
- 7. Please do not throw the old battery into your household waste for disposal. If the battery is improperly handled, it may cause the battery to catch fire and explode. Please dispose of this device, battery and other accessories in accordance with local
- 8. The battery is forbidden to be disassembled, impacted, squeezed or put into fire. If there is serious expansion, do not continue to use it.
- 9. Please keep the equipment dry.
- 10. Do not repair any product yourself. If the device or any part of it does not work properly.
- 11. When connecting other devices, please refer to the connection method of the user manual. Do not connect unsupported devices at will. To avoid hearing damage, do not use high volume for long periods of time.

Caution

- 1. Please follow the relevant laws and regulations and do not use headphones in the following environments:-
- For example, gas stations, oil depots, chemical warehouses, etc., where flammable or explosive oil or chemicals are stored, it is strictly forbidden to use equipment. Do not use this equipment in hospital operating rooms, emergency rooms, intensive care units, etc.; to avoid interference with medical equipment, please keep away from cardiac pacemakers, hearing aids, implanted cochleas and other medical equipment when using this equipment. Please keep this equipment. More than 15 cm between the pacemaker.
- 3. To use this device near personal medical devices, consult your physician and device manufacturer.
- 4. Please observe all safety warnings and regulations regarding the use of this device while driving.
- 5. To avoid lightning strikes during thunderstorms, do not use outdoors.
- 6. Do not call while charging.
- 7. Do not use the charger in a place with high humidity such as a bathroom, as this may result in electric shock, personal injury, fire and damage to the charger.
- 8. Please comply with the relevant legal provisions that are expressly prohibited in any environment.



- -Do not short the battery metal contacts, resulting in a short circuit hazard, avoiding battery burns and other personal injury caused by
- -Do not expose to high temperatures. Overheating of the battery may cause an explosion.
- -Do not disassemble, collide, squeeze the battery, avoid causing leakage, overheating, explosion; do not put the battery into the fire, otherwise it will cause fire or explosion:
- -If the battery is severely inflated, do not continue to use it.

HENZHEN FUTURE ACCESS TECHNOLOGY CO.,LIMITED.Explore more at www.hifuturegroup.com © All Rights Reserved SHENZHEN FUTURE ACCESS TECHNOLOGY CO.,LIMITED.Explore more at www.hifuturegroup.com © All Rights Reserved