

正面

90cmm

40mm





"GloryFit" APP download

Scan the QR code on the left to download the APP
 Install the APP, please register and login according to the interface prompts

*Compatible: iOS 8.0 or above/ Andriod4.4 or above.





Power ON

Press and hold the upper button for 5 seconds to turn on

Power OFF

Press and hold the upper button for 3 seconds to turn off





Set up and pair

- 1. Turn ON the Bluetooth in your smartphone
- 2. Open the GloryFit, go "Device", "+ Add a new device" 3. Search Bluetooth device & Select the "FutureFit Pulse" fo



On home screen

- Swipe down to enter the main menu
- Swipe up to enter the messages
- Swipe left to enter activity data
- Swipe right to enter heart rate,blood oxygen..











🖬 Exercise data can view steps, distance, calories ■ The phone's information wil be synced to the watch ☐ Health monitoring: heartrate, blood oxygen, sleep

Enjoy more on FutureFit Pulse



Dormant

☑ Click the button to enter the sleep state



Charging

To charge the watch, place the watch flat and make sure that the back of the two metal holes are aligned with the metal tip of the charging head.



Replace the strap

Slide the spring pin and hold it to remove the watch strap, Then connect the watch strap that needs to be replaced to the watch.



SHENZHEN FUTURE ACCESS TECHNOLOGY CO., LIMITED. Explore more at www.hifuturegroup.com $\, @ \,$ All Rights Reserved

FutureFit Pulse

Product parameter

Waterproof rating: IP68 Wa Sensor: 3 axis G-Sensor Battery capacity: 200mAh Synchronization method: Bluetooth Resolution: 240*280 pixels Display screen: 1.69 inch TFT - LCD

Working time: about 5-7 days Charging Time: About 2-3hours

Packing list

FutureFit Pulse Watch x 1 Charging Cable x 1 Quick Start Guide x 1

Regulatory Information

To view regulatory information, please go to Settings-About-Regulatory Information

Please read the instructions before use:

- The company reserves the right to modify the content of this notice without notice.
 According to normal circumstances, some functions are different in specific software versions.
- versions.

 The product should be charged for more than 2 hours before use, but avoid prolonged charging in an unmanned environment when charging.

 Please attach the magnetic charging cable to the charging port of the bracelet automatically.

 Please use the input voltage: 5V/1A or 5V/2A charging head, with the original charging cable provided by the manufacturer.

 Before using the product, please download the login application to the mobile phone, which can use the wristband time to set personal information.

Precautions

Please read this manual first to ensure safe and correct use.

- The data of this product is for health management reference only.
 Please do not use it as medical data. If any abnormal body data is found, it should be subject to hospital testing.
 The waterproof rating of the watch is IP68 Waterproof.
 You can use it normally in life situations such as handwashing, raining, etc. Please do not put the watch in hot water, do not perform operations such as underwater pressing or deep diving, and do not expose the watch to corrosion Sexual liquid to prevent damage to the watch.

Warranty Card

Customer Information:

Malfunction

Type	Seller (Signature)
Customer	Seller Tel
Customer Tel	Purchase Date
Customer Address	Seller Address

Abstrac	ct:			
Date				
Facility				

Remarks Limited Warranty

Note: Disassembling device voids warranty Note: Liquid submersion voids warranty



Documentation & Help

- (a) 1.69 inch HiRes Display (b) Heart Rate
- (240*280)■ IP68 Waterproof
- Up to 5-7 Days Daily Use
- Blood Oxygen Monitoring (25) Information Sync

Follow us

