

Palm Pro

User Manual

ASSEMBLY AND USE

- Screw the 510 thread magnetic connector onto your cartridge and drop into the slot of the device.
- Draw directly from cartridge to activate.
- *To prevent overheating, the battery will cut off any session over 10 seconds.
- *To avoid residue, remove the cartridge when not in use.

AIRFLOW SETTINGS

The gap on the airflow collar can be adjusted to increase or decrease airflow



PREHEAT SETTINGS

Start Preheat

Short-press the power button twice to start preheating.
 *A full preheat session lasts for 10 seconds with all LED lights blinking.

End Preheat

- Press the power button to stop the preheat in advance.
- To start using before the end of preheating, simply draw from the cartridge.

VOLTAGE SETTINGS

Voltage Check

. During inhalation, the LED light(s) will indicate the voltage in use.

Switching Voltages

 The default voltage is 2.8V. To switch between different voltage settings, long-press the power button and the LED light(s) will blink 3 times to indicate the voltage in use.

BATTERY AND CHARGING

Battery Level (Charging)

 During charging, the LED light(s) will blink accordingly to indicate the battery level.



Battery Level (Not Charging)

· Short-press the power button once to activate LED indication.



Charging

Remove the cartridge before charging the device.

- Insert a USB-C cable into the charging port to start charging. A full charge requires approximately 90 minutes.
- When the device is fully charged, all three light bars will blink 3 times.

· When the charging cable is detached, the lights will blink 5 times.

*Do not leave the charging device unattended or charge overnight.

OPERATING CONDITIONS

- Charger power supply: 5V, ≥500mA
- Charging temperature: 50-113°F (10-45°C)
- Working temperature: 32-140°F (0-60°C)
- Storage temperature: 64-82°F (18-28°C)
- Operating humidity: 35%-70%RH
- Storage humidity: 35%-70%RH

WARNING

- Do not expose device to water and keep away from any flammable gases and liquids.
- Do not use in wet environments or extreme temperatures.
- . Do not leave the device exposed to direct sunlight for prolonged periods.
- Do not allow other metal objects to contact electronic components in the battery.
- Keep device and accessories out of reach of children and pets.
- · Do not drop, throw, or abuse device.
- Do not attempt to disassemble device as damage and personal injury may occur.
- The device contains a lithium-ion battery and should be recycled or disposed of in accordance with local requirements to avoid potential injury and/or environmental harm.
- Do not dispose of the battery or any component of the device in a fire as
 it could cause an explosion or other serious injuries.

Warranty Terms

CCELL will provide repair or replacement according to the following terms and conditions.

- L. This warranty provides repair or replacement for defective and damaged CCELL products within 180 days from the date of purchase. Presentation of the original purchase receipt and this warranty card will be required.
- 2. The warranty does not cover repair or replacement under the following circumstances:
- Failure to provide this warranty card and the original purchase receipt.
- Product failure or damage caused by improper use, unauthorized adjustments or operating conditions out of the indicated range (see user manual).
- · Product failure or damage caused by excessive force or impact.
- Product failure or damage caused by using cartridges or accessories not intended for use with the device.
- This warranty does not cover personal items or consumable attachments, including but not limited to: cartridges, magnetic connectors, USB cables and chargers.

WARRANTY CARD

PRODUCT INFO	
Product Model	
PURCHASE INFO	
Purchase Date (YYYY/MM/DD)	
Store Name	
Store Address	
State	Zip Code
CUSTOMER INFO	
State	_ Zip Code
Phone	
Email	



CCELL DOES NOT PRODUCE, DISTRIBUTE OR SELL ANY MATERIAL FILLED IN CARTRIDGES AND OIL TANKS.

NOT FOR SALE TO MINORS.

WARNING:

REPRODUCTIVE HARM -WWW P65WARNINGS CA GOV

> WWW.CCELL.COM PATENTS: CCELL.COM/ PATENTS

FOLLOW US @CCELLOFFICIAL







