



No More Pain
Ergonomics

Work Comfortably. Work Productively.



Congratulations on your new Delux Mini Vertical Ergonomic Mouse!

This ergonomic mouse is designed specifically for small hands and includes soft touch and quiet clickable left and right buttons to create a comfortable and productive experience for its user – we hope you enjoy it as much as we do!

CONTACT US

🌐 www.nomorepainergonomics.com.au

✉ info@nomorepainergonomics.com.au

Quick Start →

Function Buttons



DPI setting
Internet navigational buttons – page forward, page back



On/off switch (Hot Tip: switch your mouse off at the end of worktime to save battery life)

1-2 switch = 1=USB receiver connection, 2=Bluetooth connection

Bluetooth pairing connection button

Storage slot for USB Receiver (USB Receiver is located here)

Laser (this will shine a red light when the mouse is switched on and active)



Battery input connection (using lightning cable)

Bluetooth connection light (flashes when ready to pair with computer)



Product Content:

- 1 x Delux Mini Vertical Ergonomic Mouse
- 1 x USB Receiver (stored in the base of the mouse)
- 1 x lightning cable

System Requirements:

- Windows 7, 2000, XP SP2, 10 or higher
- Mac OS X (10.28+)

1. Installation (USB Receiver)

- a. Switch the on/off switch to 'on' at the base of the mouse
- b. Switch the 1-2 switch to '1' on the base of the mouse
- c. Wait for the computer to recognise your new mouse (usually up to 10 seconds)
- d. Enjoy all the comfort the Delux Mini Vertical Ergonomic Mouse has to offer!

2. Installation (Bluetooth)

- a. In order to initially connect to Bluetooth with your mouse, you must connect via USB receiver beforehand – this is to navigate using your mouse on the computer screen to connect
- b. Go into your computer's Settings/Bluetooth (you should see a list of Bluetooth enabled devices)
- c. On the base of the mouse, switch the 1-2 switch to '2'
- d. Press and hold the Bluetooth connector button at the base of the mouse until the Bluetooth connector light at the front of the mouse begins to flash (see below picture in function buttons for location)
- e. 'Bluetooth4.0Mouse' will be displayed in the list
- f. On the base of the mouse, switch the 1-2 switch to '1'
- g. Move the mouse cursor to 'Bluetooth4.0Mouse' and click
- h. On the base of the mouse, switch the 1-2 switch to '2'
- i. Wait for the computer to recognise your new mouse
- j. Enjoy all the comfort the Mini Compact Ergonomic Keyboard has to offer!



3. Charging the Battery

- a. Connect the lightning cable to the mouse in the socket pictured below
- b. Connect the USB connector into an available USB port in the computer
- c. The mouse is now charging!

Troubleshooting

At times you might lose connection with the mouse to the computer. If this occurs please try the below troubleshooting steps:

- Click and ensure the mouse is in an 'active' state (the mouse will go into 'sleep' mode after a period of inactivity, clicking the left button and moving the mouse will reactivate the mouse)Mac OS X (10.28+)
- Ensure the on/off switch at the base of the mouse is switched on
- Ensure the battery in the mouse is charged – connect the mouse to a USB port using the lightning cable to charge
- Ensure the connection switch is turned to the correct connection you are trying to use (Bluetooth or USB receiver)
- Try a different USB port
- Try a different computer
- Restart your computer, then replug into the USB port
- Try a different mouse surface
- Ensure the USB receiver is close by to the mouse to stop any interference
- Ensure the sensor and surrounding area is clean from dirt or food that could be blocking the sensor connection

Usually these above tips assist in regaining the connection for the mouse.

If the above does not fix the issue, please contact us on the below:

info@nomorepainergonomics.com.au

FOR INFORMATION ABOUT:

Warranty Policy

Good Ergonomics

Other Products

Check our website: www.nomorepainergonomics.com.au



No More Pain
Ergonomics

Work Comfortably. Work Productively.