# **Spill Kit Monitoring and Replenishment** Factsheet



Spill kits are crucial for fast and effective cleanup of bodily fluids, helping to maintain a safe and welcoming environment. These boxed kits are fully stocked with everything needed for safe handling, making it easy for staff to quickly grab a kit and manage spills efficiently, reducing potential workplace hazards.

# **The Problem**

- Time-intensive management of expiry dates
- Inadequate overall visibility of statuses and locations across your business
- Manual processes for re-ordering
- Activity that does not make it to the Hazard log and an appreciation of how many clean ups there are and the cumulative risk involved

## **Business Opportunity**

- Receive notifications when a Spill Kit is removed from its holder
- Automate notifications and escalation processes to create an online audit trail
- View Spill Kit status online (via app) for all stakeholders
- Save time by automating equipment monitoring
- Integrate usage data with your H&S system for stream lined reporting

## **Clever Ecosystem**

Save money and time while enjoying peace of mind with our connected first aid ecosystem, featuring monitored cabinets, AEDs, eye wash stations, and mobile or car kits.



Location

Clever Shelf Details

History

B&V Kit added from shelf

Details

B&V Kit removed from shelf





from shelf

#### d from shelf

5,72, 6111

#### HOW TO ORDER

Please email us. We will be pleased to assist. hello@cleverfirstaid.com



SHARPS

# **Clever shelf automated reordering system** Spill Kits - Blood and Vomit



# **Clever Shelf**

The Clever Shelf holds 2 Spill Kits. Designed for easy and quick retrieval of a kit in an emergency. The Clever Shelf also monitors the presence of the kits to enable re-ordering.

### Connectivity

The Clever Shelf connects seamlessly to the internet through either a Clever First Aid cabinet or a Clever Gateway device.

### Installation

- The shelf can be attached to the wall by double sided tape, or screws. The shelf weights 550g, and each kit is 325g. the total fully loaded weight is 1.2kG
- The Clever First Aid App includes an easy setup feature that allows installers to verify that the sensors are functioning correctly.
- Dimensions 380mm x 155mm x 70mm

## Monitoring

- Sensors detect when a kit is missing and automatically initiate a replenishment.
- Kit expiration dates are monitored and Clever will automatically send replacement kits if they expire without being used.
- The Clever Shelf must be installed within the line of sight of the Clever First Aid cabinet.





# **Contents and instructions** Spill Kits - Blood and Vomit



### **Kit Instructions**

- 1. Put on gloves, apron, mask and goggles.
- Sprinkle vomit clean-up granules over the spill, covering generously.
- Leave for 5 minutes or until the fluids have been absorbed.
  Once semi-dry it can be swept away, or follow Step 4:
- 4. Cover the solidified matter with the paper towel.
- **5.** Using the paper towel, scrape the matter into the cardboard box and place in the biohazard bag.
- Dissolve the disinfectant sachet in water, as per packaging instructions, to clean the affected surface.
- Remove all personal protective items and place in the biohazard bag, then seal.
- **8.** Clean hands with antiseptic wipes and wash any contaminated skin surface with soap and water.
- Contact your state EPA-registered biological waste agent for sate disposal of the sealed biohazard bag.

#### CONTENTS

- 2 x Gloves Nitrile Blue Powder-Free
- 1 x Vomit Clean-Up Granules Sachet 120g
- 2 x Cetrimide Antiseptic Wipe Alcohol-Free
- 1 x Biohazard Bag Yellow 25cm × 30cm
- 1 x Blood Spill & Vomit Clean-Up Instructions
- 1 x Needle Stick Injury First Aid Instruction
- 1 x Apron
- 1 x Face Mask
- 1 x Goggles
- 1 x Low Lint Paper Towel
- 1 x Disinfectant Sachet 20g

#### First Aid For Needle-Stick Injury

- Wash area with running water and soap (if available) as soon as possible.
- 2. DO NOT force or encourage the wound to bleed.
- 3. Apply antiseptic and cover the area with a sterile dressing.
- Report the injury to your supervisor immediately. Seek medical advice.

