

SELECTROCIDE®

DISINFECTANT/SANITIZER/ TUBERCULOCIDE/ VIRUCIDE*/FUNGICIDE/ ALGAECIDE/SLIMICIDE/ DEODORIZER

Easy-to-use and implement disinfection kits and solutions.



SELECTROCIDE 12G KIT

ABOUT THE PRODUCT

SMT disinfection kits can be used to generate Selectrocide® products directly to hospital grade disinfection concentration. Just add appropriate volumes of water, add sachet, and allow generation.



SELECTROCIDE® 5G KIT

ADDITIONAL INFO

Registered



SMT's Products are EPA registered disinfectants proven to kill Coronavirus.

Kit Contents



Each kit contains a case of Selectrocide®, dilution tank, CIO_2 test strips, and spray bottles.

Use



- 1. Add Selectrocide® sachet to the tank.
- 2. Fill with appropriate amount of water.
- 3. Allow two hours for generation.
- 4. Once generation is complete, use spigot to fill spray bottles.
- 5. Use test strips to verify concentration of 100 PPM.
- Spray on surfaces and ensure correct contact times.

SELECTROCIDE® 1G KIT



ABOUT SMT

SMT's patented ClO₂ formula is a reliable, environmentallyaware alternative to conventional antimicrobial and cleaning solutions. By selectively targeting bacteria at a molecular level, ClO₂ effectively destroys microbial life without destroying equipment. It is extremely effective at low concentrations and does not leave residual chemicals.

CONTACT US **855-256-8299**





