

Smart watch instruction manual



Download the watch client
Scan the QR code below to download and install the watch client "Vfit" APP.



The appearance shows



Wear it correctly


The best way to wear the bracelet is behind the styloid process of the ulna. Adjust the size of the wrist according to the adjustment hole. Buckle your wrist strap. Keep the sensor close to the skin and avoid moving.
The mounting strap
1. Adjust the bayonet position according to your wrist.
2. After installing the watchband, pull the watchband properly to ensure that the watchband is installed successfully.
Change the bracelet
Ensure that the battery of the bracelet is normal after the first use. If the battery is low and cannot be started normally, please connect the charger to charge the device. Align and fit the charging port to the charging base until the charging power appears on the watch screen.

Note:
1. Please use the charging base delivered with the package to charge, and dry it before charging.
2. Connect the USB port to the mobile phone charger with output current 1A or the USB port on the computer for charging.

Watch the connection
Open the watch client "Vfit" APP downloaded and installed in your phone, click the "Devices" interface at the bottom, click "Add Watch", and click your device ID in the list of scanned devices to match.



In the time page of the watch, click the About icon, as shown in the picture above; the MAC address and ID number of the watch will be displayed. You can determine your device by the ID number in the device list. After the watch binding is successful, every time you open the client in the future, the watch will automatically connect with the mobile phone, and the data can be synchronized by pulling down the data page of the client.
After the successful connection in the APP, a pairing reminder will pop up (as shown in the picture below). Please click Pairing and connection, and only after the audio Bluetooth connection can you make a Bluetooth call.



Split screen

On the main interface, swipe right to the left to expand the split screen, and enter the split screen shortcut interface, which includes: heart rate, exercise, phone search, QR code, calculator, dialing, phone, phone book, wallet and other interfaces. Click the function button to enter the corresponding function

Message to remind
If you need to use the watch for message push, please open the message push switch in the APP after the watch is successfully connected to the APP to allow the permission of message push. You can select the APP alerts you need to receive in the message notification.

The keyboard



key 1: and rotate the button to switch the dial. Click to enter the function menu. Double click to switch the menu style. Rotate the key to slide the function menu.

key 2: and click the Recent Tasks menu. Press and hold to enter the On/Off menu

Watch Function Introduction

Interface:



They count




The smartwatch automatically tracks steps and displays on the screen, showing your calorie burn and distance throughout the day. Note: Your mobile data will reset to zero at midnight.

Call



In the connected state, switch on the call screen of the watch and tap the keyboard to initiate a dial call. (Please turn on this switch when playing music) Movement information



The watch can record and display the calories you burn during exercise, as well as mileage and real-time heart rate information. More detailed analysis and data recording can be viewed in the APP client.

Heart rate




The heart rate screen of the watch displays your current heart rate. More detailed analysis and data recording can be viewed in the APP client.

Blood oxygen




The blood oxygen interface of the watch can show your current blood oxygen concentration.

Sedentary remind



After you've been sitting for an hour, the watch will prompt you to get up and walk. The sedentary reminder function can be turned on in the client.

Sleep




The watch will automatically monitor your sleep after you wear it at night, and you can view your sleep data on the watch and APP after you get up.

The menu style



You can switch the display effect of the UI style of the watch menu in the style selection function of the watch drop-down bar view. At present, there are ten styles to choose from. Drink water to remind



Open the drink reminder in the APP terminal, and the watch will vibrate every half hour to remind you to drink water.

Voice assistant




Tap the main interface to enter the shortcut interface, click the voice assistant button, input voice commands according to the prompt, you can control the phone through the voice assistant.
(Note: This function requires Bluetooth connection. If Bluetooth is not connected, there will be no voice input prompt.)

Alipay

When the screen is on, double-click the home screen, slide right to the main menu and enter Alipay. You can use Alipay payment code or barcode to pay. Double-click the screen on the main interface to quickly open Alipay.
(Note: You need to use the Alipay app to scan the QR code on the screen to bind Alipay.)

The wallet collection




On the right side of the main interface, slide right to the main menu, enter the wallet, and you can use the payment code to receive payment. (Note: Please go to VFIT App -> Device -> wallet to bind the receipt code.)

The calculator



Slide right to the main menu on the right side of the main interface to enter the calculator, and you can use the calculator function of the bracelet.

Screen brightness adjustment




Tap the screen brightness button to enter the screen brightness adjustment interface.

Secondary menu deletion function


Slide on the main interface to enter the secondary menu interface. Long press the option of secondary menu to pop up. Click the Delete button below to delete the secondary menu that does not need to be displayed. Slide to the bottom of the main interface and click the + sign to add the deleted secondary menu again.

Stopwatch function




Enter the stopwatch and click the Start button to start the timing, click the pause button to stop, and click the reset button to clear the timing.

The weather forecast



When entering the weather screen, you can display the highest temperature and low temperature of the day. This function requires linking the APP to synchronize the time.

Find your Phone



In the connected state, enter the phone search interface and click the "Start" option, and the phone will vibrate. If the APP is not connected, it will prompt you to connect to Bluetooth.

The remote picture




In the connected state, enter the photo interface and prompt "Please open the APP terminal and shake to take photos". After the APP terminal is opened, click the bracelet to shake to take photos. If the APP is not connected, it will stop in the prompt interface.

The dial function



Long press the dial to enter the selection interface, and slide left and right to select the standby dial.

Breathing training




Enter the interface and click Start, follow the vibration rhythm to do expiratory and inspiratory training.

QR code




Click to enter the two-dimensional code interface, the displayed two-dimensional code can be scanned with mobile APP Bao, Huawei Market and other codes to download the VFit APP.

Music playback



This function needs to be connected to mobile phone Bluetooth and APP first, and can control the upnext song, pause and play on the bracelet. If Bluetooth is not connected, clicking on the interface is useless.

Restore the factory



When you enter the screen, a prompt is displayed asking you whether to restore factory Settings. Click OK to confirm that the machine will restart and the pedometer data on the bracelet end will be cleared. Use this function with caution.

Dial the market

With this function, you can select the dial to be pushed on the mobile APP. You can also add the picture on the mobile phone and push it to the watch. The massive dial needs to be downloaded on the mobile phone before it can be pushed.

Remind function

Call Reminder

In the connected state, if the call notification function is enabled, the bracelet will vibrate when there is an incoming call.
Other reminders (APP notification, sedentary, alarm clock, target, drink water) In the connected state, if this function is enabled, the bracelet will vibrate when there is a message from wechat, QQ, Facebook, etc., and the content received by the APP will be displayed. When other reminder functions are enabled, the bracelet will vibrate.

To find a bracelet

If you click this function, the bracelet will vibrate and the screen will light up. Do not disturb mode.
After this function is enabled, all notification functions on the bracelet end stop receiving notifications.

Automatic heart rate detection

After this function is enabled, the bracelet will automatically detect the heart rate, which will greatly reduce the battery life of the bracelet.

Think pat

In the connected state, start the photo taking from the bracelet terminal or enter the remote photo taking interface from the APP terminal, shake/flip the wrist/brush the bracelet, and automatically take photos after a countdown of 3 seconds. Please allow the APP to access the album to save the selfie photos.

Tips for Android users

When using the reminder function, it should be set to allow "APP" to run in the background. It is recommended to add "APP" as trust in permission management and open all permissions.

Frequently Asked Questions and Answers

Why does blood pressure value have deviation with sphygmomanometer?

Watches is the trend of dynamic blood pressure measurement, watches and blood pressure measurement in the numerical deviation due to a variety of

external factors, you at ordinary times is brachial artery blood pressure monitor is used to measure the parts measurement, the watch is in the artefice are the main two branches, under normal circumstances the main artery will and artefice measurement vary by 30-40, if you at that time is measured at the same time. And because of the flow of blood in the artery is centrifugal direction, blood pressure measurement of your elbow below the center of the side due to pressure, temporary blood has no way to flow smoothly to the following arterial branches; There is increased vascular tension, which leads to greater deviation in blood pressure measurements.

Why can't the watch receive notifications?

Android phone Settings:
1. Confirm that the message push switch is enabled on the mobile client and the watch APP is allowed to obtain relevant control rights. 2. Check whether the notifications can be displayed normally in the notification bar of the mobile phone. If there is no message in the notification bar, the watch will not receive a push.
(You need to find the notification Settings in the mobile phone Settings, and turn on the stop switch of wechat, QQ, phone, SMS and mobile phone clients. Permission to read messages by running APP) 3. Open the watch client's accessibility Settings.
(Find the auxiliary function in the mobile phone Settings and open the auxiliary function Settings on the watch client)

iPhone Settings

1. Ensure that the message push function is enabled on the mobile client. 2. Open the mobile phone Settings -> click Notification -> click wechat, SMS, Phone -> enable the allow notification and confirm that the message can be displayed normally in the mobile phone notification bar.
Note: The push failed after the connection. It is recommended that you click ignore device in Bluetooth Settings, disconnect the connection, restart the watch and bind the watch again through the client.

Why can't watch a hot bath?

Not recommended for hot showers.

One of the main causes, water vapor from hot showers
The temperature of the bath water is relatively high, easy to produce a lot of water vapor, and water vapor is a gas body, its molecular radius is small, easy to penetrate into the shell gap from the watch, when the temperature will gradually condense into water drops, thus damaging the watch circuit board,

and then damage the watch.
Why is GPS not available on APP display?

You need to turn on the GPS function of the mobile phone first, and affected by the GPS signal of the mobile phone, you cannot receive the signal indoors, and you need to go to the open place to receive the GPS signal.

Why are there no sleep records?
The watch records your sleep time from 8 PM to 10 am the next day. Wearing the watch to sleep automatically monitors your sleep status.

Should the Bluetooth connection always be on? Will the watch data be saved if disconnected?
The exercise and sleep data are saved on the watch console until they are synchronized. When the watch is connected to the mobile APP, the watch data will be automatically synchronized and uploaded to the mobile APP. The watch can store data for about 7 days. When the space is full, the system will automatically cover the earliest data. Please pay attention to the timely synchronization of data to the mobile APP.

* Note: If you need to enable the call and message reminding function, you must keep the watch Blue tooth connected to the APP, and support offline after the alarm is set successfully.

Why does Bluetooth occasionally fail to connect?
The Bluetooth service of some mobile phones will occasionally appear abnormal when starting, which leads to the failure of Bluetooth connection. Usually, the connection can be established normally by restarting the mobile phone or re-switching the Bluetooth.

Special statement

1. Do not wear it when bathing or swimming.
2. Connect the watch to synchronize data.
3. Use the built-in charging cable to charge the battery.
4. Do not put the watch for a long time exposed to high moisture, high temperature or very low place.
5. System support: Android9.0, iOS9.0 and above.
6. Non-professional blood pressure measuring equipment, watch measuring blood pressure parameters for reference only, not for medical use.
7. Due to the continuous upgrading of product functions, the specific instructions shall be subject to the APP user manual.

