

Original Rev: 3/13/18



Thank you for purchasing a TrueTrac Simple Square!

An accessory that offers a quick way to perform 90-degree cross cuts has been a customer requested item for many years.

The hold-up on the product was simply the cost associated with machining our design.

So, we made the leap and purchased a moderate sized CNC Mill (Tormach 1100) and have since started to manufacture more of our smaller components in-house.

As always, it's our goal is to provide exceptional service and excellent products. If at any time you have an issue, give us a call at 1.937.544.6855 or send over an email to jacob@truetracsaw.com

All the best, Richard, Darlene, and Jacob Rhodes

Tools Required:


- 5/32 hex key for shoulder bolts (not provided)
- 1/8 hex key for locking set screws (not provided)
- 90-degree reference square (speed square, machinist square, etc)
- Flat and stable work surface.
- TrueTrac Pro-Series track section of your choice
 - Pro-Series = Original track, beveled edges, dovetail connectors

Items Provided:


- One (1) TrueTrac Simple Square
- Four (4) 5/16 diameter ¹/₄-20 thread shoulder bolts
- Two (2) 12-inch length self-aligning connectors (set screws installed)



1) Install the 12" connectors to the Simple Square with the provided shoulder bolts - Barely finger tighten the bolts at this point



- TRUETRAC	Simple Square Assembly Instructio		Current Rev:	3/13/18
The Better Track Saw System			Original Rev:	3/13/18
 4) Tighten the four set so were installed in the 1 connectors a. This aligns the connectors track section 	2" long			
5) Use a 90-degree refere against the front face of Square and the edge of section being used	of Simple			
 6) Ensure no gaps exist – a. Having the four should relatively loose allows adjustment to match the track 7) Tighten the shoulder the "X" pattern once the garemoved and double cyour reference square tightened 	ler bolts for he edge of the oolts in an aps are heck with			SUIIII



If you have any problems, <u>please let us know</u> so we can take care of it.

If the product meets your expectations, please share your feedback via a product review!

Reviews can be left on the individual product pages below the product description section.