# **Technical Information Sheet**



# QuickSeam™ Cover Strip

## 1. Description

The Firestone QuickSeam™ Cover Strip is a 152 mm (6") wide semi-cured EPDM strip laminated to a QuickSeam tape. The strip is used to cover and seal butt-joined Firestone RubberCover™ EPDM membranes.



#### 2. Preparation

The RubberCover™ EPDM surfaces must be prepared with QuickPrime™ Plus, using a QuickScrubber™ tool. Use of other products is not allowed. Restore the product to room temperature prior to use if exposed to temperatures below 15°C for prolonged periods.

# 3. Application

Place the roll of cover strip on the membrane, positioned so it unrolls from the top of the roll (release paper will be on top) and center the cover strip over the exposed membrane edge(s). Unroll the cover strip onto the clean and primed surface. Advance the roll keeping the strip centered over the membrane edge(s) and peel the release paper as you apply the strip.

### 4. Coverage

In accordance with length of seam to be covered. Adjoining QuickSeam Cover Strips require an overlap of 25 mm and a cover patch.

#### 5. Characteristics

Technical		
	EPDM Flashing	QuickSeam Tape
<ul> <li>Base</li> </ul>	EPDM	Rubber polymers
<ul> <li>Color</li> </ul>	Black	Black
<ul> <li>Solvents</li> </ul>	None	None
<ul> <li>Solids</li> </ul>	100%	100%
<ul> <li>State</li> </ul>	Semi-cured	Cured
<ul> <li>Thickness</li> </ul>	1.02 mm	0.88 mm
<ul> <li>Width</li> </ul>	152 mm	156 mm

# 6. Packaging / Storage / Shelf Life

Packaging	7.62 m (25') rolls, 8 rolls per carton
Part number	W56RAC1693

**Storage:** Store in original unopened containers at temperatures between 15°C and 25°C. Keep the material out of direct sunlight until ready for application.

**Shelf Life:** 12 months can be expected if stored in above-mentioned conditions. Shelf life information is only a recommendation and not a fact of life. The real expiration date highly depends on the history of storage and handling of the accessories. Quality and applicability should thus always be verified: QuickSeam Cover Strip can be used only as long as the release paper can easily be removed from the tape without tearing the paper apart.

# 7. Precautions

Refer to Safety Data Sheet.

