

GPSR

DERBLAUE® Service Set



1. PRODUCT DESCRIPTION

The DERBLAUE® Service Set is a flexible fluid collection system designed for professional use in the maintenance and repair of machines and vehicles. It enables the clean collection and targeted drainage of liquids such as oil or hydraulic fluids, even in areas that are difficult to access. The Set consists of a flexible Professional Tub, a Slide and a Single-Splash-Guard and is supplied in a bag.

[DERBLAUE®](#)

2. SCOPE OF DELIVERY

- **Professional Tub:** Made from special fabric-reinforced tarpaulin with integrated bending metal elements.
 - **Slide:** With hanging tab, strong neodymium magnet and integrated bending metal elements.
 - **Single-Splash-Guard:** With 22 mm opening and integrated bending metal elements.
 - **bag:** For storage and easy transportation of the Set.
-

3. TECHNICAL DATA

- **Professional Tub:**
 - **Material:** Fabric-reinforced special tarpaulin
 - **Capacity:** 10 liters
 - **Dimensions:** 34 cm x 34 cm x 12.5 cm
 - **Weight:** 580 g
 - **Slide:**
 - **Dimensions:** 30 cm wide at the top, 20 cm wide at the bottom, length 50 cm
 - **Attachment:** Neodymium magnet and eyelets
 - **Single-Splash-Guard:**
 - **Opening:** 22 mm
 - **Suitable for pipe diameter:** 21-26 mm
-

4. SAFETY INFORMATION

- **Application:** The Set is designed for collecting and draining non-aggressive liquids such as oil, hydraulic fluids and glycol-containing liquids.
 - **Handling:** Avoid contact of the components with sharp or pointed objects to prevent damage.
 - **Storage:** Clean the parts after use and store them in a dry place to ensure the longevity of the material.
 - **Temperature resistance:** The materials are suitable for use in a temperature range from -20 °C to +70 °C.
 - **Warning:** Not suitable for drinking water. This product is intended exclusively for non-potable liquids. Use in drinking water systems may impair water quality.
-

5. LABELING AND TRACEABILITY

- **Manufacturer:** Aqua Evolution Systems GmbH
 - **Brand:** DERBLAUE®
 - **Product name:** Service Set
 - **Item number:** 13015
 - **Contact address:** Aqua Evolution Systems GmbH, Lindenstr. 14, 87477 Sulzberg Germany
 - **Website:** store.derblaue.com
-

6. OPERATING INSTRUCTIONS

Assembly and use of the DERBLAUE® Service Set

1. **Prepare the Professional Tub:**
 - o Unfold the Professional Tub and shape it according to the operating environment using the integrated bending metal elements.
 - o Position the Professional Tub under the area to be serviced to collect liquids.
2. **Attach the Slide:**
 - o Attach the Slide to the sump or Single-Splash-Guard using the neodymium magnet and eyelets to direct liquids into the sump.
3. **Using the Single-Splash-Guard:**
 - o Place the Single-Splash-Guard around pipes with a diameter of 21-26 mm to act as a splash guard.
 - o Combine the splash guard with the Slide to drain liquids in a controlled manner.
4. **After use:**
 - o Empty and clean the Professional Tub and Slide with clear water and a mild detergent.
 - o Allow all components to dry completely.
 - o Fold up the Professional Tub and store the entire Set in the bag provided.

7. RISK ANALYSIS

- **Mechanical risks:**
 - Possible damage due to improper handling (e.g. by sharp or pointed objects).
 - **Measures:** Careful handling and avoid contact with sharp objects.
- **Chemical risks:**
 - Possible material damage due to aggressive chemicals.
 - **Measures:** Only use the components with recommended liquids.
- **Risk of slipping:**
 - Escaping liquids can make the work area slippery.
 - **Measures:** Ensure that the collected liquid is removed in good time.

8. DECLARATION OF CONFORMITY

Manufacturer:

Aqua Evolution Systems GmbH
Lindenstr. 14| 87477 Sulzberg| Germany

Aqua Evolution Systems GmbH hereby declares that the DERBLAUE® Service Set complies with the requirements of EU Regulation 2023/988 on general product safety (GPSR).

Date: 12.12.2024

Signature: 
Position: CEO

9. CLEANING AND MAINTENANCE

Clean all parts of the Service Set, especially the Slide, the bag and the Professional Tub, after each use with warm water and a mild detergent.

Dry all components completely before folding or storing them. Store the Service Set in a dry, cool place and protect it from direct sunlight and aggressive chemicals.

10. MAINTENANCE AND INSPECTION

Before each use, check the bent metal elements on the Professional Tubs and Slides for deformation and carefully straighten them if necessary.

Regularly check all materials, seams and attachment points for cracks, signs of wear or other damage.

Replace damaged parts immediately to ensure safe and efficient use of the Service Set.

11. DISPOSAL

- **Environmentally friendly disposal:**
 - Dispose of defective or no longer required components of the Set in accordance with local regulations.
 - Plastic and metal parts can be recycled.
 - Electronic components such as the Battery and Power Supply Unit must not be disposed of with household waste. Contact a suitable recycling center.
-

12. WARRANTY AND CONTACT

For warranty inquiries or further information, please contact: DERBLAUE® Customer Service

by e-mail: service@derblaue.com

Phone: +49 8376 3269961