

series 47 - getting started



 +44 (0)121 524 1400
 radleywatches@peershardy.co.uk

www.radley.co.uk/smart-watches-instructions/

1. Place the back of the watch case onto the magnetic charging pad.
Note: Watch must be laid flat to ensure successful charging.
2. Switch on power, charging will begin.
3. Please charge the band when it displays low battery.
4. A 2 hour charge time is sufficient to fully charge your smartwatch.
Please take care not to overcharge.

1. Press & hold the crown for 3+ seconds to turn your smartwatch ON or OFF.
2. You can also tap the POWER OFF icon within the menus, confirm your selection when prompted and your smartwatch will switch off.

Your smartwatch has access to our signature dials, to switch between them press & hold the screen and swipe left or right to view. Once you have selected your dial, tap to set. Alternatively, you can access your dials by tapping on the dial icon on the APP homepage.

You can scroll through the dials using the crown. To lock a dial and stop the crown from scrolling, hold down on the dial screen & tap the lock.

Enjoy the convenience of viewing the time home & away on one single screen. Select the dual time dial on your watch, then go to APP to select the city of the second time zone, both time zones will then be displayed on your dial.

Tapping on this icon will turn on the bluetooth connection and allow you to connect to your phone. Once connected you can answer calls and play music from your watch.

Screen brightness

Sleep mode

Tap on the 'About' to see the Bluetooth address and software version of your smartwatch.

Settings

Swipe up on the dial interface to view notifications such as incoming calls, text messages, Instagram, WhatsApp, Facebook, X, etc., and delete them automatically after reading.

To download our app, search for the RADLEY App. or scan the appropriate QR code with your smart phone camera.

The RADLEY app will work on the following smartphones:

- Android (version 9.0 and above)
- Apple IOS (version 12.0 and above)

Please ensure the app is the latest version and have Bluetooth 5.2

1. Enable Bluetooth on your smart phone.
2. Open the RADLEY App. on your smart phone.
3. Review and accept privacy policy.
4. Set your preferences and follow the set up guide.
5. To connect your watch, tap the green icon & select your watch from the list.
 - Allow permissions when prompted to gain full functionality of your watch.

1. Tap **DISCONNECT DEVICE** in the settings menu & click OK to confirm.
2. To disconnect your watch from your smartphone, click **DISCONNECT DEVICE** in the settings menu, then go to the Bluetooth settings on your phone & click **FORGET THIS DEVICE**.

When the watch face is displayed, swipe right on the watch face to enter and view the menu screen.


Starting the activity within your APP will utilise the phone GPS and improve activity accuracy.

Tap the sport icon to enter 'multi sport mode'.



To end sport mode and save the sports data simply swipe right on the screen and press the stop icon.

Swipe to set a sport goal.



A reminder will pop up when you have reached your set goal.


- By tapping the speaker icon you can adjust the volume by swiping on the volume bar.
- Mute call.
- Answer call on watch.
- Answer call on phone.

RADLEY

LONDON

CALL RECORDS

Tap on 'call records' to see your recent call history.



Tap on this icon in watch settings to clear all call records.

HEART RATE MONITOR



Tap this icon to monitor your current heart rate. To exit the heart rate monitor swipe right on the screen.

BLOOD OXYGEN MONITOR



Tap this icon to monitor your current blood oxygen level. To exit the blood oxygen monitor swipe right on the screen.

SLEEP MONITOR



Monitor your sleep 24/7 and sleep data on watch & in the app.

STRESS MONITOR



Our stress monitor will help you keep an eye on your stress levels throughout the day.

WEATHER



Display the weather when the smartwatch connected to RADLEY APP.

SEDENTARY REMINDERS



Turn on the sedentary reminder you've set in the RADLEY app. Your watch will vibrate to remind you to take a little exercise.

SHUTTER




Take pictures remotely from your smart watch.

MUSIC CONTROL



Tap the music icon to enter the music playback control interface. You can select previous/next song, and play/pause music. From here you can also control the volume.

VOICE ASSISTANT



When the watches call bluetooth is enabled you can utilise your phone's built in voice assistant.

SOS FEATURE



When the watch is connected via bluetooth the SOS feature allows you to quickly sound an alarm when in an emergency situation to alert others around you or make an emergency call from your watch.

- Press & hold the crown for 3+ seconds and select SOS option.
- The alarm will sound on your watch and phone.
- Alternatively within settings select SOS feature to make an emergency call to your emergency contact.

Note: Our Personal Safety Alarm is designed to help draw attention should you find yourself in an uncomfortable situation. Your safety and wellbeing are of paramount importance, so please take care to always adhere to safety advice.

SETTINGS



Find your smartphone as long as the watch and APP is connected (within 10m).



Power saving: Save your battery percentage by using this function. Screen brightness will be lowered.



Brightness: Tap here to adjust (+/-) the screen brightness.



Audio setup: Toggle BT connection settings on and off.



Screen Duration: Change how long the screen stays on for.



Information notification: Toggle which message notifications you'd like to receive on your watch.



Dial Option: Swipe left and right to select your favourite dial.



Health monitor: Toggle health monitor on and off.



Menu View: Choose between list view and grid view.



Switch setting: Toggle which reminders you'd like to be set.



Language: Set the language.



Restart: Restarts your watch.



Reset call: This will clear all call data on the watch.



Reset: This will clear all data on the watch and reboot.



Vibration intensity: Change how much your watch vibrates.



Power off: Switch off your smartwatch.



Calculator



SOS: Use this feature in an emergency situation.



Notification: Switch on and off notifications and how they appear.



Do not disturb: Switching this on will lower your brightness and will turn off the 'wake up' feature. All reminders will also be disabled except for the alarm clock.



System: Find the BT address and software version of your smartwatch.

HOW TO CARE FOR YOUR SMART WATCH

Do not wear your smartwatch whilst applying sprays or creams. Do not allow contact with any corrosive agent e.g. paint, solvents or adhesives, as this may affect the finish of the smartwatch. Do not try to replace or disassemble the battery.

STRAP CARE

Environmental conditions can affect the durability of your strap. Please treat it with care and limit exposure to direct heat or sunlight. Keep your watch dry and away from wet surfaces. Do not use chemical cleaners on your strap and avoid contact with cosmetic products, such as fake tan or perfumes. Light soiling can be cleaned using a weak soapy water solution on a barely damp soft cloth. Please be aware light coloured straps i.e. whites, creams and pastel colours, are prone to attract colour transfer from other surface materials and cosmetic substances. Please take care whilst wearing these products as discolouration of straps is not covered within the guarantee.

SILICONE STRAP CARE

To keep your silicone strap looking good, clean it regularly with mild soap and water to remove any dirt, oils, lotions etc., ensuring the case of your smartwatch does not get wet. When you are not wearing your smartwatch, we recommend you store it in the gift box received with purchase.

BRACELET WATCHES

Take care to avoid bending the bracelet beyond the normal curvature of the wrist. It is recommended the watch be kept in the gift box when not in use. Avoid placing the watch under heavy objects or loose in a handbag.

LEATHER STRAP CARE

RADLEY watches use carefully selected leathers of the highest quality standards. Variations in the colour and grain are natural characteristics of the leather. Environmental conditions can affect the durability of your strap, please treat it with care and limit exposure to direct heat or sunlight. Keep your watch dry and away from wet surfaces. Do not use chemical cleaners on your strap and avoid contact with cosmetic products, such as fake tan or perfumes. Light soiling can be cleaned using a weak soapy water solution on a barely damp soft cloth. When you are not wearing your watch, we recommend you store it in the gift box received with purchase.

MESH BRACELET

Unlock the clasp by using an appropriate tool. Move the entire clasp to adjust length by sliding along the bracelet. Adjust the length while wearing the watch to make sure you get a good fit. Make sure the clasp locates into a moulded indent on back of the bracelet. Lock the clasp plate in position by pressing it into place using your thumb. DO NOT use the retaining bar to gain leverage as this will cause damage preventing the clasp to lock.

STEP COUNTER

Smartwatches use multiaxis inertial sensors called accelerometers. These detect wrist movement in order to measure steps. However, some wrist actions whilst standing or sitting can mimic the arm movement of a step and can therefore falsely record steps. The step count recorded each day should be used as a guide only.

WATER RESISTANCE

IP68 standard guarantees water resistance for 30 minutes up to a maximum water depth of 1.5 metres. We do not recommend our watches for use in saltwater. Always rinse your smartwatch after swimming.

GUARANTEE

Quality and style are at the heart of what we do. RADLEY certifies this smartwatch is produced using premium materials and is fully tested before leaving our manufacturing centre.

Your RADLEY smartwatch is guaranteed against any defective parts and construction for 2 years from the date of purchase. Your guarantee is only valid if you present your original receipt when returning the item. This guarantee provides you with rights in addition to your consumer statutory rights and therefore does not limit your statutory rights. Please note this guarantee does not cover lenses, bands, straps or bracelets, water penetration or batteries. Additionally, breakages caused by accident or maltreatment are not covered.

All products should be returned to: PH Services, Precision House, Unit 4, Starley Way, Solihull, B37 7GN.
Please contact us before sending in your product and we'll guide you through the process.

CONTACT US

If you require any further assistance using your RADLEY smartwatch or our RADLEY App we are here to help!

You can also contact the RADLEY customer service team Monday to Friday, 9AM to 4PM on:

 +44 (0) 121 524 1400  radleywatches@peershards.co.uk

There is also lots of information on our website <https://www.radley.co.uk/smart-watches-instructions/> that you may find helpful.

PRIVACY POLICY

Please check <https://www.radley.co.uk/smartwatchprivacypolicy/> to view our privacy policy. Please remember to check for updates periodically.

IMPORTANT SAFETY INFORMATION - BEFORE USING THE PRODUCT, PLEASE FAMILIARISE YOURSELF WITH ALL OF THE SAFETY INFORMATION AND INSTRUCTIONS FOR USE!

BATTERY WARNINGS Do not attempt to replace the battery, open the device enclosure or disassemble your RADLEY product. Doing so can result in a safety hazard · The integrated rechargeable battery cannot be removed or replaced · Substances within RADLEY smartwatch battery may harm the environment or cause injury if handled or disposed of improperly. In the unlikely event of contact with battery acid, thoroughly flush the affected area with plenty of clean water and seek IMMEDIATE medical attention · When the battery is fully charged disconnect from charger, DO NOT exceed 2 hour charge time.

DEVICE WARNINGS This is a Class A product. In a domestic environment, this product may cause radio interference. In which case the user may be required to take adequate measures · Ensure your smartwatch correctly engages with the charging contacts · Before each use, please check the product for damage, do not use if the product is damaged · This is not a toy, children should not play with this product · Never attempt to open your smartwatch, this may result in danger · Protect the product from strong impacts, vibrations, direct sunlight and dirt · Do not place heavy objects on the product · Do not exert pressure on the product · Avoid strong magnetic fields e.g. loudspeakers · Salt and thermal water can lead to the corrosion of metal parts. Remove the product before using saunas as the temperature difference can cause condensation · Do not operate the product near heat sources e.g. radiators or other devices emitting heat. Do not cover the product during operation or charging · Never use the product on aeroplanes, in hospitals, service rooms, or near medical electronic systems. The wireless signals transmitted could impact the functionality of sensitive electronics · Do not use your RADLEY product if the display is cracked · Do not expose your RADLEY product to extremely high or low temperatures · Do not use abrasive cleaners to clean your RADLEY product · Remove your RADLEY product immediately if it feels warm or hot · Do not attempt to wear or operate your RADLEY product whilst charging · Do not charge your RADLEY product if wet · Do not check notifications or other applications on the products display while driving or in other situations where distractions could be hazardous. Always be aware of your surroundings when using RADLEY products and services · Ensure your smartwatch is removed at regular intervals for gentle cleaning.

HEALTH WARNINGS RADLEY smartwatches contain components that emit electromagnetic fields, with some of the models containing a magnetic charging dock, please be aware that these models contain magnets. These electromagnetic fields and magnets may interfere with medical devices, such as pacemakers and implanted defibrillators. Please consult your doctor and medical device manufacturer if you use any medical device before using a RADLEY smartwatch · The RADLEY heart rate monitor is designed for recreational use only, it is not intended for any medical use such as diagnosing or monitoring any medical conditions · The RADLEY heart rate monitor periodically emits flashing lights, please consult your doctor before use if you have epilepsy or similar conditions · The RADLEY heart rate monitor usually provides an accurate estimate of your heart rate, but the reading can be affected by factors such as fit of the smartwatch, the physical characteristics of the wearer and the intensity of the activity · Your RADLEY smartwatch will help calculate distances covered and calories burned during training. Please consult a doctor before starting new exercise regimes · RADLEY smartwatches contain sensors to track your movement to closely estimate your activity, sleep, calories used etc. These close estimations are not always fully accurate · Some wearers may suffer skin irritation if the smartwatch is worn for prolonged periods. Sensitive skin, skin allergies and medication could contribute to the irritation incurred and should be considered before use. If you notice any irritation you should remove your smartwatch. To help prevent any irritation please ensure the smartwatch is removed regularly for cleaning & do not over-tighten on your wrist · We recommend you remove your smartwatch each day for gentle cleaning.

In the case of material damage or personal injury caused by incorrect handling or non-compliance with the safety instructions, no liability can be accepted by RADLEY. If you have any questions or concerns, please contact us, you'll find our contact details on this leaflet.

DECLARATION OF CONFORMITY - To view our declaration of conformity certificates, or If you have any questions or concerns, please contact us, you'll find our contact details above.

Manufactured by: Peers Hardy UK Ltd, Precision House, Starley Way, Birmingham Business Park, Bickenhill Lane, Solihull, B37 7GN, UK.
EU Address, Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands.

DISPOSAL OF GOODS · The crossed out wheellie bin symbol is to remind you that waste electrical products, batteries and accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility.

- Do not dispose of your RADLEY product within household waste.
- Disposal of your RADLEY packaging and product should be done in accordance with local regulations.
- Batteries are not to be disposed of in municipal waste & require separate collection.