

Please carefully read this manual before using the product

Introduction

The iGear Magcharge Pro uses high-quality batteries and IC. demonstrating outstanding safety, efficiency, and compatibility performance. It supports both wired and wireless charging and is specifically designed for iPhones with wireless charging capabilities. It's important to note that the magnetic absorption and charging performance may be affected by third-party protective cases.

To wirelessly charge a phone that supports wireless charging. simply place your phone on the powerbank, the phone will get attached to the wireless charging pad. The power bank will automatically detect it and start charging the phone.

Warning

Improper use may lead to battery failure, overheating, and even fire or explosion. Please keep and use this product in accordance with the following guidelines in order to avoid personal and property injury:

- · Charge this product with a charger that meets local safety standards to avoid electric shock or damage to the battery. · Do not use the product (both charging and discharging) in
- places with poor ventilation, such as inside clothes, under pillows, bedding, and other items. This product must not be disassembled, squeezed, punctured. or short-circuited and should not be placed in water or fire (including near heat sources such as stoves or heaters.
- or exposed to environments with temperatures exceeding 140°F) In case this product is deformed, leaks, overheats, etc., stop
- using it immediately and dispose of it properly. . The power bank, battery and other accessories should be disposed of in accordance with local regulations and not disposed of as household waste. An improper handling of the battery may result in the battery explosion.

removed. Do not disassemble this product without permission. For your safety, do not attempt to replace the battery yourself. . To prevent accidents, keep this product out of reach of children.

An integrated battery is included in this product and cannot be

Precautions

· Before the first use, please fully charge the product

- Use an adapter and charging cable that meet the appropriate
- specifications to charge the power bank and use the power bank for wired charging. · Keep the wireless charging pad clean and free of foreign
- objects when the power bank is used for wireless charging. If the mobile phone has a protective case, make sure that the case is non-metallic and is not thicker than 3 mm.
- Please make sure that someone is present while this product is charging, and please unplug the power supply if you are going to be absent for a long time. Unplug the charging cable after the product is fully charged.
- or completes charging a mobile phone. To avoid loss as a result of prolonged connection, please remove your device from the power bank after the wireless charging is completed. If the product does not display the battery level after you press the button, it may be in a protection state. In that case you can charge the power bank to restore it. Keep the power of this product at about 50% when not using it for a prolonged period of time, and store it in a cool and dry
- powerbank in a fully charged or uncharged state for a long period of time. Keep the power bank away from magnetic cards with magnetic strips or chips (such as ID cards and bank cards) to

environment. To extend the battery life do not store the

prevent loss of magnetism. For safety reasons, please keep this product at least 20 cm. away from implanted medical devices (such as pacemaker and cochlear implants).

Product Overview

1. Power Input - Type C

2. Power Output - Type A USB and Type C

Model: iG-1269

Battery Type: Lithium-ion battery

Specifications

Battery Capacity: 10000mAh Wired Output: 22.5W Wireless Output: 15W Max.

Operating Temperature: -10~45°C Sensing Distance: ≤3mm-6mm Item Dimensions: 10.5cm x 7cm x 1.75cm

Warranty

Warranty period: 1 Year In case of consumer complaints: Customer Care - +91 9372667193 Email: support@igear.asia (Between 10am to 5pm, Mon-Fri) www.igearworld.com

