

# U.V. SANI

## OPERATING INSTRUCTION

	<p>Indication:</p> <p>Epiray Sanitizer utilizes hospital grade germicidal Ultra Violet irradiation to effectively sanitize implements and tools evenly from top to bottom. It is recommended, to obtain best result, to initially clean and disinfect implements and tools prior to subjecting them to irradiation.</p>
	<p>Specification:</p> <p>Voltage: 110V (220V Option)          Frequency: 50 – 60 Hz          Power: 8W – 10W          Working Temperature: 41° F to 104° F          Unit Size: 14" X 8" X 10"          Carton Size: 17"L X 10"W X 12"H          Gross Weight: 15 lbs</p>
	<p>Caution:</p> <p><b>DO NOT LOOK DIRECTLY INTO THE ULTRA VIOLET LIGHT BULB WITH NAKED EYES. EXPOSURE TO ULTRA VIOLET LIGHT IS INDICATED TO CAUSE HARM/INJURY TO THE UNPROTECTED EYES.</b></p> <p>Requirement:          The objects being sanitized must conform with the basic requirements. The objects to be sanitized must not be unusual in compositions and/or physical structures/shapes which by their inherent characteristics will cause limitation in germicidal effect of Ultra Violet irradiation.</p> <p>Application and Usage:          Epiray Sanitizer is a professional grade sanitizer that utilizes hospital grade germicidal Ultra Violet irradiation to effectively sanitize implements and tools evenly from top to bottom. For best result, first clean and disinfect implements and tools before running through Ultra Violet irradiation.</p> <p>Epiray Sanitizer can also be used to store sanitized implements and tools until they are used.</p> <p>It is recommended that the implements &amp; tools be irradiated for at least 5 to 10 minutes for best result.</p>
	<p>Operating Instructions:</p> <p>The Epiray Sanitizer is available with a tray. Implements and tools may be placed on the upper and lower compartments when irradiating.</p> <ul style="list-style-type: none"> <li>• The On/Off switch is located on the top right corner of the Sanitizer.</li> <li>• To use the Sanitizer, (1) connect the unit to the power source and turn "On"; and (2) place objects into the Sanitizer then close door.</li> <li>• The Ultra Violet lamp will automatically shuts off whenever the door opens.</li> <li>• When finished, turn "Off" unit.</li> </ul>

Maintenance & Cleaning:

- It is advised to regularly clean the Sanitizer with moistened towel. Disconnect unit prior to cleaning.
- Do not use solvents or abrasives to clean the Sanitizer.
- Do not submerge Sanitizer Unit into liquid.
- It is recommended that Sanitizer Unit is serviced by Authorized Service Personnel only.
- Do not shake or drop Sanitizer Unit.
- Keep unit dry.