



**KELLER INTERNATIONAL, LLC**

1431 LAKE RD, HAMLIN NY 14464

Info@kellerinternational.com

T: 1-800-578-8772 • F: 1-585-964-8093

KELLER4SALON.COM

## **TD-207 UV Hot Towel Warmer Directions**



### **Function:**

- This towel warmer is used for heating dry and damp towels, warming cosmetics, storing sterile instruments and accessories (sponges, brushes, napkins, etc.).
- The sterile environment will hold about two-dozen small hand towels (when rolled up) while maintaining a temperature of approximately 158°F (70°C) to 176°F (80°C) depending on the temperature of the room it's in.
- The number, condition and type of towels used will dictate the warm up time.
- Unit has a bottom tray for capturing moisture released from inside the unit – empty daily.

**NOTE:** This Towel Warmer is NOT a Sterilization Unit. It will ONLY maintain a sterile environment (the inside walls) for ALREADY sterilized equipment.

**NOTE:** Please follow all Local and State regulations regarding sterilization. Additional requirements may be necessary.



- Unit should always be used with the stainless steel basket.
- Load dry or damp clean towels or other items and turn HEAT "ON":
  - Internal temperature should reach maximum in about five minutes.
  - Turn all switches to "OFF" when unit is not in use.



Voltage: 110V – 120V / 60Hz  
Power: 220W  
5A 250V Fuse

- **DO NOT** place heavy items or bottled liquids on top of the unit which may scratch the enamel paint surface and cause rust.
- **DO NOT** drop the unit as this may cause the unit to malfunction.
- **DO NOT** disassemble or attempt to repair this unit.
- **DO NOT** connect the power cord to an improper outlet.
- **DO NOT** damage the power cord or bend the power plug prongs.
- **DO NOT** plug this unit into an outlet with too many other items in the same outlet.
  - Check the power plug regularly to ensure it is dust free and firmly installed.
- **DO NOT** submerge this unit – it is not waterproof.
- **DO NOT** use this product outdoors or in a humid environment.
- **DO NOT** put heavy objects or pressure on the unit's door when opened.
- **DO NOT** use the unit without the stainless steel basket:
  - During operation, the inner box surface, basket and the door backboard are extremely **HOT** – **CAUTION** should be used when adding or removing the towels.
  - Too many towels inside unit may touch the inner box surface which is extremely **HOT**.
- **NEVER** leave any towels in the unit at the end of the day:
  - Remove the basket; wipe up any remaining water drops or moisture inside the box or on the basket.
  - Leaving any moisture in the inner box or on the basket may cause odors.
- **REMOVE** the drain water tray (under the unit) before it overflows and discard.