

## Technical Update - Published 27/07/23



Mahlkonig has advised during the manufacturing programming stage there is potential for the software to glitch causing the burr health counters to prematurely alarm.

As this is quite rare please note this alarm will display “Service Required” up to 10kgs of use and can be easily reset by following this guide.

After resetting this alarm the burr health will act accordingly to:

E65SGbW = 800kgs

E80S & E80GbW = 1200kgs

1. Double tap on the jog dial.
2. Scroll down and Enter <Setting>
3. Enter <Safety + Passwords>
4. Enter <Login>
5. Scroll to “123”
6. Enter password 9512867. Scroll to icon <<↵> and enter
7. Select the back button (Top Left Hand Button)
8. Enter <Service> then scroll down to “Service Tools”
9. Enter <Confirm Service> then <Confirm>

