



- support@audioarray.in @audioarray.in
- audioarray.in @audioarray.in
- /c/AudioArray @audio_array



AM-C42

AUDIO ARRAY

INSTRUCTION MANUAL

CONDENSER MICROPHONE



1. Product Diagram



- 1 Microphone 4 Cable Tie 7 USB Cable
- 2 POP Filter 5 Microphone Stand 8 Mic Windscreen
- 3 USB-A to Type-C Adapter 6 Table Clamp

2. Installation

Step 1 check the accessory list.



POP Filter



Microphone



Shock Mount



Cable Tie



USB-A to Type-C Adapter



Microphone Stand



USB Cable



Table Clamp



Mic Windscreen



Step 2, fix the clamp on the edge of the table.



Step 3, insert the foot base (black) of the adjustable microphone stand into the the table clamp.



Step 4, tighten the screw.



Step 5, Screw the shock mount onto the threaded end of the adjustable microphone stand.



Step 6, insert the microphone into the microphone clip.



Step 7, fix the pop filter on the adjustable microphone stand to complete the assembly.



Step 8, Connect the microphone to the computer or mobile phone, use headphones to monitor the audio output directly through the microphone.

3. Specifications

Polar Pattern:	Cardioid
Max sampling rate:	192KHz/24Bit
Sensitivity:	-42dB±3dB (1kHz 0dB=1V/Pa)
Max. SPL:	125dB (1kHz) ≤1%T.H.D.)
Frequency Response:	20Hz-20kHz
S/N Ratio:	70dB

4. What's in the Box

1 x USB Condenser Microphone	1x Microphone Stand
1x Windscreen	1 x USB Cable
1x Table Clamp	1 x Shock Mount
1x Pop Filter	4 x Cable Tie
1 x 3/8"to5/8"Adapter	1 xUSB Adapter
1 x User Guide	