

FUTURISTICLIGHTS



AETHER GLOVE SET

Setting Up Your Gloves

1. Remove the battery pull tab sticking out of the back of each Aether.
2. Place each Aether in a finger of a glove. Make sure the buttons are all facing the same direction.
3. Put the gloves on your hands. You can either have the lights on top of your fingers (resting on your fingernails) or on the bottom (resting on your finger pads). Either way, make sure the buttons are facing away from your fingers so you can press them. Experiment and see what works best for you!

Using Your Aethers

1. Click the button once to turn on the Aether to its first slot.
2. Continue to click the button to cycle through the 7 available slots on the chip.
3. To turn off the Aether, hold down the button until the light turns off, then release. Continuing to hold down the button will access the Mode Control Features.

Color Palatte



Color Selection

You can select up to 15 colors for each slot of the Aether.

1. Navigate to the slot you wish to edit.
2. Hold the button down until the light turns off; continue holding down until it turns BLUE (1st color), then release.

3. The light will start pulsing white. To cancel color selection, hold down from here until the light flashes. Otherwise, you can click to cycle through the 38 colors available.

4. When you've found a color you like, hold down until the light flashes. If you release now, that color is selected. If you keep holding down, the light will cycle through the three brightness levels. Release on the brightness level you want.

5. After each color selection, you will be taken to Demo View, where you can see how the slot looks so far. You can continue selecting colors, or hold down until the light flashes to finish color selection.

6. If you select the maximum of 15 colors, the light will flash and exit color selection.

Mode Selection

To enter Mode Selection, navigate to the slot you would like to program, and hold the button down until the light turns GREEN (second color). Here you can click to cycle through the 13 different modes of the Aether. To choose a mode, hold down the button until the light flashes and let go. You can choose the same mode to be programmed in more than one slot if desired.