## ColorFit Spark UM - 84 x 84 mm

FIND PHONE

User Manual for ColorFit Spark

This feature helps you find your mobile device by making it ring. Just tap on 'Find phone', and your

phone will start to ring, even if it is on Silent mode.

TABLE OF CONTENT

• What's in the Box

Watch Overview

· Charging the Watch

Watch Navigation

About

09 User Manual for ColorFit Spark

Tap on About to view the device information.

You can select this option to power-off the watch.

• Turn the Watch on and off

USING COLORFIT SPARK SMARTWATCH

usage and other factors.

11 User Manual for ColorFit Spark

CHARGE COLORFIT SPARK

Before using your ColorFit Spark for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a full charge, ColorFit Spark can last up to 7 days.

Note: The battery life and time to fully charge your device may vary as per

PACKAGE CONTAINS

• Noise Health

Sports

Noise Buzz

Scan easy

10 User Manual for ColorFit Spark

Messages

POWER ON

• Press and hold the side button for a few seconds to turn on the watch.

You can update your ColorFit Spark via the NoiseFit app. In the app, select 'Me', go to 'Settings' & check for version update.

You can find the watch's current firmware on the watch. Go to 'Settings' & select 'About' to know the current firmware version. On the NoiseFit app,

select 'Device', choose 'Device Version' to know your current firmware version

How do I find my watch's current firmware version?

12 User Manual for ColorFit Spark

• Press and hold the side button for a few seconds.

Select 'Power Off' to confirm.



The ColorFit Spark smartwatch has a TFT touchscreen. Navigate the

watch by tapping on the screen, swiping side to side, up and down

Press the side button to turn on the watch display.

and pressing the side button.

SIDE BUTTON NAVIGATION

13 User Manual for ColorFit Spark

APP SETUP

Before pairing, make sure that your smartphone and smartwatch are next to each other. The app will ask for personal information such

as height, weight and sex to calculate your stride length, distance

covered, calorie burn rate and metabolic rate. When you set up you

account, your name and profile picture will be visible to other use

These limits are designed to provide reasonable protection against

harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation

harmful interference in a residential installation. This equipmen

14 User Manual for ColorFit Spark

• Turn on Bluetooth and the location on your mobile device.

DIAL PAD

CONTACTS

contacts and make calls.

Access the dial pad to make calls.

This feature allows you to view your stored

clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stiffness in your hands or wrists while or after wearing

the watch, please immediately discontinue use.

15 User Manual for ColorFit Spark

SCAN EASY

17 User Manual for ColorFit Spark

18 User Manual for ColorFit Spark

ou can save QR code in the app.

of your current location.

ap on the Weather app on your watch to see the weather

Tap on 'Sleep' to view your previous sleep records. You can view your most recent sleep records and sleep

ColorFit Spark supports viewing the highest and lowest value

quality in various sleep stages on the NoiseFit app.

BLOOD OXYGEN

16 User Manual for ColorFit Spark