



Your e+Series device must be configured before use!

Step 1: Access the e+Series device configuration screen using your browser. Here is an explanation of how to do this.

Connect the e+Series device's Ethernet connector to an Ethernet hub, and run another Ethernet cable from that hub to your laptop or PC. Make sure that the laptop or PC is the *only* other unit in this small LAN. **NOTE:** If you do not have a hub, you can use a "**crossover cable**" to connect between the e+Series device and your laptop.

Set your PC's IP address to **192.168.88.90** with a subnet mask of **255.255.255.252**.

Open your browser and enter the following URL: <http://192.168.88.89/admin>

You will be prompted to login:

User=admin password=admin

The Cimetrics default password is a secure mixture of letters and numbers but also can be remembered because of the relationships of these keys on your computer keyboard.

From within the browser interface you can change all settings in the entry fields to configure your router

For improved access security, you should change your password from the default values. **Make sure you SAVE your new password!** Clicking on "Save Configuration" followed by "confirm" saves the changes made to the configuration.

Now disconnect your laptop and connect the B6000 into your BACnet networks.