

QUALITATIVE RESPIRATORY FIT TEST KIT

PRODUCT DATA SHEET: **RFTK**



PRODUCT CODE: **RFTK**

FEATURES & BENEFITS

- Qualitative fit test kit in accordance with AS/NZS 1715:2009 requirements.
- Ensures accurate respirator fit.
- Suitable for all close-fitting negative pressure respirators.
- Tests are Simple and easy to complete.
- Re-usable for multiple tests.

PRODUCT DETAILS

- Kit Contents:**
- 1x Fit test solution.
 - 1x Sensitivity solution.
 - 2x Nebulisers.
 - 2x Nebuliser cleaner wires.
 - 1x Test hood and collar.
 - 1 x Storage box.

CARE INSTRUCTIONS

CLEANING:

At the end of each session or at least every four hours, discard the unused solutions from the nebulisers.
 Warning: DO NOT pour unused solution from nebuliser back into bottle, unused solution must be disposed.
 Rinse the nebulisers with warm water to prevent clogging and shake dry. Wipe out the inside of the hood with cloth or paper towel to remove any deposited test solution.

STORAGE:

Store in a cool dry location, out of direct sunlight in supplied packaging.

FIT TEST

Provides the wearer with a pass or fail result on the respirators ability to seal effectively against the wearers face.
 There are two types of Fit Tests – Qualitative & Quantitative.
 Qualitative tests are usually simple & fast but may be influenced by the wearer.
 Quantitative tests are not subjective or influenced by the wearer, however, involves the purchase of expensive equipment & a fully trained operator.
 Records of either tests must be kept for each wearer & stored to form part of the respiratory program.

A Fit Test should be performed at appropriate interval:

1. When there is a change in the wearer's facial characteristics, e.g. weight loss/gain or removal of teeth.
2. Before the respirator is used by the wearer to ensure the chosen respirator is suitable.
3. A further fit test should be performed at least once annually.

STANDARDS

To be used in conjunction with:
 AS/NZS 1715:2009 -
 Selection, use & maintenance of respiratory protective equipment.

AVAILABLE IN

PRODUCT CODE	QTY	CARTON
RFTK	1 piece	6 pieces
RFTK-H	1 piece	50 pieces
RFTK-N	1 piece	50 pieces
RFTK-B	1 piece	10 pieces
RFTK-BFTS	1 piece	10 pieces



QUALITATIVE RESPIRATORY FIT TEST KIT
 PRODUCT CODE: **RFTK**



REPLACEMENT HOOD (WITHOUT COLLAR)
 PRODUCT CODE: **RFTK-H**



NEBULISER (TWO STICKERS INCLUDED)
 PRODUCT CODE: **RFTK-N**



PRE-MIXED BOTTLE - SENSITIVITY SOLUTION #1
 PRODUCT CODE: **RFTK-B**



PRE-MIXED BOTTLE - FIT TEST SOLUTION #2
 PRODUCT CODE: **RFTK-BFTS**

www.prochoicesafetygear.com

PERTH
 T [618] 9301 7888
 E wa@paramountsafety.com.au

MELBOURNE
 T [613] 9764 9900
 E vic@paramountsafety.com.au

SYDNEY
 T [612] 9601 3877
 E nsw@paramountsafety.com.au

BRISBANE
 T [617] 3806 2699
 E qld@paramountsafety.com.au

ADELAIDE
 T [613] 9764 9900
 E sa@paramountsafety.com.au

NEW ZEALAND
 T [649] 525 8090
 E nz@paramountsafety.co.nz