EMF STIFFY PIN INSTRUCTIONS

TO BE USED IN THE UPPER BALL JOINT WHEN THERE IS A STIFF KNUCKLE AFTER INSTALLING EMF BALL JOINTS (MOST COMMON IN 2006-2007 YEARS BUT CAN BE SEEN IN OTHER YEARS AS WELL)

1. Remove the set screw from the side of the body completely. Do not lose this part, you will need it later.	2. Remove the cap counter clockwise using a spanner wrench.
3. Inside the upper ball joint you will notice a pin, race and spiraloc holding the race inside.	4. Pull the pin out and leave it aside with the race you are going to take out. You can use this as a rebuild kit for the other ball joint later on if you wish.
5. Locate the end of the spiraloc with a pick. Get the pick underneath it (can be a pain).	6. Using the pick, remove the spiraloc.
7. Remove the race. Do not use the existing race with the stiffy pin or it won't work. The Stiffy Pin comes with a special race designed to work together.	8. Replace the race with the stiffy pin race. (it has a groove on the top so you can tell the difference)



