

EB-416

Tube Grip Dispensing Pliers INSTRUCTIONS

GOODSON

Tools and Supplies for Engine Builders

156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847

Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

EB-416

Please read instructions before using.

April 2013

Directions:

Simply slide the crimped end of the tube between top rocker plate and the bottom handle until the crimp extends past the end of the plate. Progress the tube further into the opening as the material is dispensed until the tube is completely flattened.

CAUTION:

The Tube-Grip™ can generate enough pressure to burst a tube containing partially cured material. It should be used with good quality material only. Do not use the TUBE-GRIP™ to unclog nozzle tips. Always read the instructions for application and safety that are provided with the material being applied. Eye protection is recommended.