

# SA130 / SB731 / SD931 CALIBRATION

- ◆ To turn on while the scale is counting backward to zero, press and hold **ZERO**
- ◆ until the display appears the program version no. "02001". Then, release your finger from **ZERO** key, the display will appear "F0" in the calibration mode.

Press **▲** or **TARE** key to select **F0** function ⇒ the screen displays **F0**

F0

Press **↓**

Zero

Press **↓**

0.0000 kg

**Calibrated unit for "kg" or "lb"**  
Press **UNITS** key

Press **▲** and **↓**  
to input the "calibrated weight"\* value

003.0000 kg

Press **↓**

3.000 kg

Put inputted weight on the scale,  
Press **↓**

WAIT

While stable  
Buzzer "beep"

3.000 kg

F0 calibration is finished return to weighing mode

**▲** = key for moving up  
(0,1,2,3,4,5,6,7,8,9)  
**↓** = key for confirmation  
**CE** = cancel and return to F0 mode

**"calibrated weight"\***  
should be over 0 weight or any weight less than the full capacity of scale.

