



## Installation Diagram For Loading Bin Light Switch

1. Safety First! Remove Fuse or Turn Off Circuit Breaker that provides power to the Light Switch used in this room.
2. Remove the Light Switch Cover Plate
3. Cut the "COM" (usually Black) wire. Strip insulation off each end.
4. Attach stripped ends of extension wire you have cut to the run length required to reach from the Light Switch to the Back of The Loading Bin. Cap the exposed ends.
5. Replace the Light Switch Cover Plate.
6. Attach the stripped ends of the extension wire to the two wires protruding from the Back of the Loading Bin Switch. Cap the exposed ends.
7. Replace the Fuse or Turn On the Circuit Breaker you disconnected in Step #1.
8. The Loading Bin Switch is now installed in Series with the Light Switch. With the Light Switch in the "On" Position the Overhead Lights should go OFF when you life the lid of the Loading Bin.

