

PULSAR® 510 VLT

USER MANUAL

SPECS:

Size: 3.38 x 1.65 x 0.71 inches
Maximum Cartridge Size:
11.5mm diameter/61mm length
Battery Capacity: 650mAh
Voltage: 2.8V / 3.4V / 3.8V
Charging: USB-C
Resistance: 0.8-2.0 Ω
Static Current: ≤10uA

KIT INCLUDES:

1 x Pulsar 510 VLT
1 x USB-C Charging Cable
1 x Magnetic Ring for 1ml cartridge
1 x Magnetic Ring for .5ml cartridge

POWER ON:

Press the top button 5 times to turn the device on or off.

PRE HEATING:

Press the top button 2 times within 1.5 seconds or inhale quickly 2 times to start the pre-heat function. Colorful rainbow lights will flash to indicate that it is pre-heating. To stop the pre-heating, press either button 1 time.

ADJUSTING VOLTAGE:

Press the button 3 times within 1.5 seconds or inhale 3 times quickly to adjust the voltage. The corresponding light color for each voltage will flash 3 times when selected.

2.8V Green (Low)

3.4V Blue (Medium)

3.8V Red (High)

BATTERY LEVEL INDICATOR:

With the VLT powered on, press the top button one time quickly and the light will indicate the current battery voltages.

Green: 75% or more battery

Blue: Between 35%-75% battery

Red: Below 35%

VAPING INSTRUCTIONS:

1. Charge the battery using the provided USB-C cable. Plug into the connector on the bottom of the unit and attach the cable to a 5v power source. The red light will turn on when it is connected and charging. The charge time is approximately 80 minutes.
2. Allow the battery to fully charge before use. The light will turn green when the device is fully charged. Disconnect the device from the cable when it is fully charged.



3. Open the lid of the VLT and remove the included magnetic connector and screw it on the bottom of a 1ml cartridge (if using a .5ml cart, please use the larger magnetic connector).
4. With the magnetic connector attached to the cartridge, drop the cartridge inside the cartridge slot and close the lid.
5. If the unit is turned off, press the button 5 times to turn it on.
6. Adjust the voltage by pressing the button 3 times or inhaling on the mouthpiece 3 times. (Green Light = 2.8V, Blue Light = 3.4V, Red Light = 3.8V).
7. Pre-heat the device by pressing the button 2 times or inhaling on the mouthpiece 2 times. Colorful rainbow lights will flash to indicate that it is pre-heating.
8. Press and hold the button or inhale slowly to vape. The current voltage light will activate and remain on while vaping. If you vape for 10 seconds the device will automatically time out.

ELECTRIC LIGHTER INSTRUCTIONS.

1. If the unit is turned off, press the button 5 times to turn it on.
2. Open the lid of the VLT.
3. Pull up and pivot the silicone heat guard off the lighter coil.
4. Press the lower button and wait 1 second for the coil to get hot enough to light your joint.
5. Press the end of the joint against the coil while inhaling on the filter side.
6. Replace the silicone heat guard and close the lid.

Note: Lighter will turn off automatically after 10 seconds of continuous use.

PRO TIP

The VLT has built-in storage for an extra magnetic ring located in the top of the lid. This can hold the 0.5ml or 1ml magnetic ring.

IMPORTANT SAFETY WARNINGS

- Do not expose to extreme temperatures or direct sunlight.
 - Do not drop the device or accessories.
 - Do not drop or submerge in any liquid.
 - Do not modify the electronics in any way.
 - This device is intended for adults only. Do not sell or provide to minors.
- Keep all parts, concentrates, herbs, and liquids away from children and pets. This is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, personal injury, and may void warranty.

LIMITED WARRANTY

Pulsar products are guaranteed from manufacturer defects or malfunction from the original date of purchase for a period of 6 months. This limited warranty protects against manufacturer defects under normal use and does not apply to normal wear and tear, improper use, and accidental damage from dropping or submerging in liquid, improper cleaning, neglect, or any other damage that is not a result of defective materials or workmanship. If your device qualifies, we will replace, at our discretion and expense, any defective parts or materials. Purchaser must provide a copy of the original dated sales receipt and may be required to provide shipping to return defective parts or materials. We intend to complete all replacements within 7 business days, although this timeframe may vary depending on shipping, replacement part availability, or other related factors. The lawful and proper use of this device is a condition of sale. Any improper use of the device will void the warranty. Warranty is non-transferable. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

PULSARSHOP.COM

