

# **TECHNOLOGY**

#### Active Technology:

Ion exchange, ultra-powdered activated carbon.

Antimicrobial: Yes

Chemical-free: Yes

BPA free materials: Yes

Size: 2.9" (7.3 cm) H x 3.1" (7.8 cm) W

Weight: 3.8 oz (108 g)

Fast Flow Rate: 8 seconds per 24oz

(5 liters/minute)

Lifespan: 350 presses (250L/65 gal)

**Shelf Life:** Stored under proper conditions, an unopened Purifier Cartridge has a shelf life of 10 years. After a cartridge has been used, it lasts at least 3 add'l years.

### REMOVES

VIRUSES ( 99.99% )

ROTOVIRUS, NOROVIRUS, HEPATITIS A

BACTERIA (99.9999%)

E. COLI, SALMONELLA, DYSENTERY

PROTOZOA (99.9%)

GIARDIA, CRYPTOSPORIDIUM, AMOEBAE

### **FILTERS**

#### **PARTICULATES**

MICROPLASTICS, SEDIMENT, SILT

#### CHEMICALS

CHLORINE, BENZENE, CHLOROFORM


#### **HEAVY METALS**

LEAD, ARSENIC, CHROMIUM

## 350 PRESSES 250 L / 65 GAL 51 / MIN

## ONE PRESS™ 8 SECONDS

### **PURIFIER LIFESPAN**



Purifier cartridge is designed to last 350 cycles (65gal / 250L) - about 3 uses per day for 4 months, if used everyday. Always use the clearest, cleanest water possible. Lifespan will decline when purifying water with high levels of silt, sediment or tannins. The cartridge press time increases towards the end of the cartridge lifespan - when press time reaches 25-30 seconds, the cartridge should be replaced. Cartridge continues to protect, even as press time increases.

### **CARTRIDGE REMOVAL**



#### REMOVAL

Firmly grasp the Inner Press. Rotate the cartridge **counter-clockwise** until it separates from the Inner Press.

## **CARTRIDGE INSTALLATION**



#### INSTALLATION

Firmly grasp the Inner Press. Insert cartridge into the bottom of the Inner Press.

CAUTION: Proper installation of cartridge prevents cross-contamination.



#### ROTATE & LOCK

Rotate the cartridge **clockwise** until you feel the cartridge firmly lock into place. The cartridge will stop rotating once it's locked.

## **PRECAUTIONS**

#### NO FREEZING

While a single freeze/thaw cycle does not degrade a cartridge, repeated cycles do. If it happens once, thaw slowly. More than 2x freezing cycles, replace your cartridge before using. Protect your GEOPRESS Purifier in freezing temperatures: keep full of water, insulate in a lacket or sleeping bag.

#### NO HOT OR BOILING WATER

Do not expose cartridge to water hotter than 140F (60C), it will harm purifier media.

#### NO MICROWAVES

We don't know why you would put your cartridge in the microwave, but if you're thinking it may help dispel some lingering squiggly wigglies, or you're just curious. We warn against the temptation.

#### SOURCING THE BEST WATER

GEOPRESS removes impurities from virtually any freshwater source. However, common sense suggests starting with the cleanest (least silty) water available. For instance, streams are generally better than lakes (which are often have higher levels of sediment and tannins).

#### WARNING / HAZARD

GEOPRESS removes impurities from virtually any freshwater source. However, common sense suggests starting with the cleanest (least silty) water available. For instance, streams are generally better than lakes (which often have higher levels of sediment and tannins).

#### CROSS-CONTAMINATION

Proper installation of cartridge prevents cross-contamination. Do not expose/fill the Inner Press with untreated water.

#### ACCIDENTAL DROPS

Withstands drop tests (at full capacity) up to 10 feet (3 meters).

# **CARE BETWEEN USES**

#### DON'T USE SOAP ON CARTRIDGE

Do not wash the Purifier Cartridge with soap or other cleaning agents. Soap will damage the purifier media. You may rinse the cartridge with clean water as needed.

#### PROPER CARE & STORAGE

The Purifier Cartridge can last up to 3 years after opening if cared for properly between uses. After use, air dry cartridge completely (2-4 days). Clean other parts with soap and water. Reassemble all GEOPRESS parts and close lid tightly. Left exposed to the air, the powdered carbon can degrade over time.

# **WE HAVE YOU COVERED**

### RECYCLE YOUR USED CARTRIDGE

To participate in our zero waste cartridge recycling program, please visit us at: www.grayl.com/recycle

### PARTS AND CONTACT INFORMATION

For replacement parts, purifier cartridges, performance ratings, frequently asked questions, or to contact us with questions or comments, please visit us at: www.grayl.com

### INTERNATIONAL MANUALS

Manuales / Manuels / Manuali / Handbücher www.grayl.com/manuals

#EMPOWERADVENTURE



1631 15TH AVE W #208 SEATTLE, WA 98119 877.293.7861