



in partnership with Haven Technology
Made in America Since 1993

Cleaning Procedures for Haven Window Intercoms

Haven Technology has reviewed our intercom products and has the following recommendations to ensure cleanliness and reduce the potential for germ transfer. Window intercoms may be cleaned with commercially available household disinfectant wipes. **If you use a spray disinfectant, do not spray directly on any part of the intercom.** Apply disinfectant to a soft cloth like microfiber, then wipe down the unit.

When cleaning:

- Follow the disinfectant manufactures directions for use.
- Remove any excess liquid from the cloth/wipe to avoid getting cleaning solution into ports and other openings.
- Wipe intercom with a clean microfiber-type cloth to remove any residual left by the cleaners. Do not use a sponge or abrasive cleaning surface.
- **Do not spray disinfectant directly onto the intercom.** Spray onto cloth and then clean the intercom unit.

Haven Technology cannot make a determination of the effectiveness of a given disinfectant product in fighting pathogens. Please refer to your local public health authority's guidance on how to stay safe from potential infection.