



BrightFlex

Rechargeable LED Light

User Guide

Read all instructions prior to using your new product.

USING YOUR BRIGHTFLEX RECHARGEABLE LED LIGHT:

- If the blue LED battery indicators are not illuminated, "wake up" the battery bank by pressing the battery bank button on the side of the battery bank opposite of the clip. Blue LED lights will illuminate to show the current battery level.
- Once "awake", turn on the light by pressing the power switch located on the top of the light head. Press it again to begin cycling through the three light levels (90 | 45 | 20 Lumens, and off).
- Your BrightFlex Rechargeable LED light uses energy efficient LEDs which will never need to be replaced.
- The BrightFlex is powered by an included 2500 mAh rechargeable battery.
- The battery fully charges in 3.5 hours (using the included 4 meter micro USB charging cable,) providing 8, 15, or 25 hours of illumination, depending on the brightness level being used.
- The light head can be removed, and be powered by any USB port, including laptops, other battery banks, etc.
- When the light head is removed, the battery bank can be used to charge small electronics like cell phones or tablets (charging percentage will vary based on the capacity of the battery within your particular device). Ensure battery bank is awake to charge.
- The clip can be removed from the battery bank to reduce overall size (ideal for travel or when on-the-go).
- The rechargeable battery is FAA compliant and can travel inside an airline cabin. Never put rechargeable batteries in checked luggage.

SAFETY INFORMATION:

- This product is not a toy and is not intended for children under 13 years of age. Do not stare directly into the LEDs or shine them into the eyes of others. Do not attempt to remove or replace the LEDs.
- Improper use of this or any other battery operated product may cause batteries to leak or explode, which may result in chemical burns and/or personal injury.

If any amount of battery leakage comes in contact, directly or indirectly, with skin, eyes, inside of mouth, or anywhere on body: 1) immediately flush the affected area with plenty of cool, running water (do not use hot water). 2) Contact your local doctor, Poison Control Center, or hospital emergency room, or call the 24 hour National Button Battery Ingestion Hotline at: 1-202-625-3333, which accepts collect calls from both the US and Canada.

Also, give the hotline number to your doctor or hospital emergency room. If injury appears serious, call: 911.



Power switch with 3 dimming levels

Audience light shield

Detachable clip

Screw-on light connector

Battery Bank
(2500 mAh)

Micro USB charging port



CUSTOMER SERVICE:

For questions and assistance please contact us at:
800.922.3233 • customerservice@mightybright.com

Visit us at:
www.mightybright.com

