

WATERCHECK™ LITE SAMPLING INSTRUCTIONS



Step 1 Please read all of the instructions before starting.



Step 2 Freeze the blue ice pack. After the blue ice pack has been in your freezer for at least 8 hours, you can collect your water sample from an appropriate water faucet or spigot.



Step 3 Run the cold water for approximately 3-5 minutes, then adjust flow to a thin stream to avoid spashing or overfilling.

Fill the 500 mL plastic bottle to the neck, cap securely and return to the shipping container. (Bottle pictured to the right).



Step 4 Complete the enclosed lab form, making sure to indicate the collection date and time you sampled, type of water, and sample identification (e.g. kitchen sink, well head, ect.) Return the blue ice pack to the kit and place the kit back in the cardboard box with the completed lab form.

National Testing Laboratories, Ltd. 1-800-H2O-TEST | www.watercheck.com
 For Laboratory Use ONLY
 Sample Number: _____
 Date Received: _____
 Time Received: _____
 Product: _____
 Date Sampled: _____
 Time Sampled: _____
 Sample ID or Location: _____
 Order Number: _____
 Order Date: _____
 SO#/To: _____
 Name: _____
 Address: _____
 City/State/Zip: _____
 Phone: _____
 Email: _____
 List Additional Analysis: _____
 INCORRECT INFORMATION MAY DELAY ANALYSIS AND/OR INVALIDATE RESULTS
 WHITE - Return To Dept In-Bu-Labatory - YELLOW - Customer Care - PINK - Resale Only

One or the other

Please Retain This Portion for Your Reference!
National Testing Laboratories, Ltd.
 1-800-H2O-TEST | www.watercheck.com
 Order Number: _____
 Order Date: _____
 Product: Watercheck 1&2
 Date Received: _____
 Time Received: _____
 Sample Number: _____
 Date Sampled: _____
 Time Sampled: _____
 Sample ID or Location: _____
 Order Number: _____
 Order Date: _____
 SO#/To: _____
 List Additional Analysis: _____
 INCORRECT INFORMATION MAY DELAY ANALYSIS AND/OR INVALIDATE RESULTS

*See reverse side for step 5



It is not necessary to ship by an overnight delivery service. Make arrangements to ship the kit by Ground service [or drop the kit off at our laboratory, Monday to Friday, 8:30 am to 5:00 pm] to the following address:

**National Testing Laboratories
556 South Mansfield Street
Ypsilanti, MI 48197**

**Get Your Kit to Our Lab Faster by
Purchasing Expedited Shipping from NTL.**

Take advantage of reduced overnight and 2 day return shipping rates by purchasing United Parcel Service labels from National Testing Laboratories.

Call a Technical Sales Representative for details at
800-458-3330.



NOTE: *Testing & reporting takes approximately 5-7 business days. Heavily contaminated samples may take longer to process. Turnaround time can vary due to laboratory volume. Results will be emailed upon completion.*

NOTE: *The lab reserves the right to reject water samples that appear to be excessively contaminated as they may cause potential damage to laboratory equipment.*

If you have any questions regarding this Watercheck™ Lite Test or any other services we provide, please contact a Technical Service Representative at National Testing Laboratories at 1-800-458-3330 for assistance.

Thank you for choosing National Testing Laboratories, Ltd. for your water testing services!