# Selleys Liquid Nails Instant Hold / Hold Up / Soudal T Rex Power Fast Grab

## Instructions for use







## How to use the product

- 1. Ensure surfaces are clean and free from grease or loose particles
- 2. Use a high thrust caulking gun and the supplied V-notch nozzle to apply in vertical stripes. Ensure the V shape is angled upward when applying.
- 3. Position materials and press together firmly. Due to the high initial hold of the product support during curing is not necessary.
- 4. Holds instantly but must not be disturbed until cured (up to 48 hours).
- 5. Adjustable e.g. can be straightened for up to 15 minutes



### **Handy Tips**

- Clean up with turps before the adhesive cures
- Safety Information
- KEEP OUT OF REACH OF CHILDREN.
- Avoid skin and eye contact and breathing vapours.
- Use in a well-ventilated area.
- Wash hands after use.
- If on skin: Wash with soap and water.
- Product releases methanol during cure. Refer to Safety Data Sheet.

#### Storage & re-use

- · Cure product before disposal
- Store in a cool place.
- The adhesive should be used within 6 months after opening.
- If the adhesive is going to be used again within a few days, leave the nozzle on and merely extrude approximately 2cm of product before storing the cartridge upright. This will cure to a plug which can easily be pulled out when required.
- For longer storage periods, leave the nozzle on and place a piece of plasticine or Blu Tack over the end of the nozzle. Tightly tape a piece of aluminium foil over the whole nozzle to exclude any air.
- When you want to re-use the product, simply take off the foil and plug from the old nozzle pull out the
  excess adhesive from the nozzle with a corkscrew, then re-pierce any cure at the tip of the cartridge and
  re-use.
- If cure has taken place into the cartridge, the product is unlikely to be in a useable state and should be disposed of

